Modern Shower Walls

Installation Instructions

2mm Thick

White

Adhesive not included






Available sizes 2000mm (H)

W1 To suit 900mm x 900mm Base Actual size 875mm x 875mm I/N: 4890197

W2 To suit 1200mm x 900mm Base Actual size: 1170mm x 870mm I/N: 4890198

W3 To suit 1000mm x 1000mm Base Actual size: 975mm x 975mm I/N: 4890199

W4 To suit 1500mm x 900mm Base Actual size: 1470mm x 875mm I/N: 4890628



IMPORTANT TO READ BEFORE INSTALLING

Please inspect this product for damage or manufacturing fault prior to commencing the process of installation, no warranty will be applied after installation has begun.

Prior to installation, please ensure there are no pipes or cables hidden in the wall where you intend to drill for the purpose of installing your shower screen once you have completed the installation process of your acrylic wall liner.

Each shower wall has a protective film on the surface of wall liner. Do not remove the protective cover until the shower wall installation is complete.

Please refer to the supplied installation instructions to guide you through the installation process. Before you commence installation, refer to the Components List within the instructions along with the list of tools required to execute the installation.

We highly recommend that you cover the shower base area with a protective cloth through-out the installation process to avoid damage to your shower base.

Tools Required

Level Drill Mallet Silicone (Must be non-acidic) Silicon Gun Pencil

Stanley Knife Tape Measure 35 mm Hole Saw

Masking Tape

Check the measurements of your wall and ensure you have the correct size acrylic wall liner to suit your shower area.

Check all angles and levels and ensure the area is true and square. You may need to pack or modify wall liner where necessary.

Measure, mark and drill holes on the rear of wall liner for shower outlet and tap fittings.

Trial fit the acrylic wall liner and tape into position using masking tape and mark lightly around the outside edge of wall liner with a pencil. Remove wall liner.

Ensure that both surfaces are clean dry and grease free. Failure to do say may cause wall liner to come unstuck during use and will void warranty.

Apply a liberal bead of silicone horizontally to the joint between villa board and shower base, prior to applying wall liner,

Apply a 5mm bead of shower wall lining adhesive onto the villa board in vertical lines spaced 100mm apart. Within the marked perimeter.

Place the acrylic wall liner on to the glued wall with in 10 mins of applying glue and firmly press the entire sheet using your hands so that full contact is made with all beads of adhesive.

Brace the full area of your acrylic wall liner firmly for at least 18 hours by using off cut of wall board & props placed on a 45 degree angle to brace the wall liner to the wall boards.

Each shower wall has a protective film on the surface of wall liner. Do not remove the protective cover until the shower wall installation is complete.

Apply a fine bead of bathroom purpose silicone horizontally, where the wall liner and base meet sealing there area from leaking.

Place silicone around tap spindles and shower rose outlet avoiding any water leaks

- Do not use shower for at least 24 hours.
- Do not apply blobs of adhesive, this will cause the sheet to buckle and will show lumps in the acrylic liner.
- Do not apply wall liners on painted surfaces, treated surfaces or water proofed membranes.

Rick McLean's Designer Shower Screens (Aust) Pty Ltd

Trading as Rick McLean's Designer Bathware

WARRANTY

Measured & Installed Products

Rick McLean's Designer Bathware will provide a 2 year Service Warranty on installation and componentry of measured & fitted Shower Screens, Mirrors & Sliding Robe Doors. Cracked, smashed or broken Glass, Splashbacks and Mirrors are NOT included. Warranty does not cover glass. Replacement glass is covered by the customer's house & contents insurance policy (if applicable) or at the customer's own expense.

Supply Only Products

Rick McLean's Designer Bathware will provide a 2 year Warranty on our supply only products. Warranty does not cover glass. Replacement glass is covered by the customer's house & contents insurance policy (if applicable) or at the customer's own expense.

Rick McLean's Designer Bathware will supply a replacement product where faulty manufacture or faulty materials exists, only in accordance with correct installation procedure.

This warranty DOES NOT apply to other defects which may have arisen as a result of; accidental damage, misuse, abuse, maltreatment, wear & tear, incomplete return, abnormal stress or neglect of any kind.

This warranty DOES NOT include REMOVAL AND/OR INSTALLATION COSTS and any other associated expenses incurred, including those costs incurred from third party.

It is the responsibility of the recipient to inspect the product/s once received to ensure no transit damage has occurred, and/or missing parts or manufacturing faults are applicable.

Plumbing and Bathware products must be installed by a licensed plumber. Failure to do so will immediately void warranty.

Failure due to other causes, including the use of other than recommended installation procedures, may also void warranty.

Please ensure that plumbing and bathware products are installed in accordance with local by-laws.

Please ensure glass and fragile products are handled with care. Avoid knocks & shock to all sides of packaging when transporting.

Freestanding Baths are not designed to be installed hard up against bathroom walls. The sides of the baths taper, even if they appear to be straight edged. Installing freestanding baths up against tiled walls or recessing baths into walls and tiling down onto them is at the client's own discretion. This is not in accordance with correct installation procedure and will void warranty.

Sizes, Prices and Stock Availability of products are subject to change without notice.

Warranty does not cover glass.

Broken Glass or missing parts will not be replaced under warranty if the Shower Screen is in the process of being installed.

The safety glass featured in all Shower Screens cannot be cut, trimmed or altered in any way.

Manufactured sizes of Shower Screens, Shower Bases & Baths are nominal. Actual sizes may vary during manufacturing.

How to make a claim for Credit or Exchange of Goods for Supply Only Products

Rick McLean's Designer Bathware will credit or exchange goods within 14 working days from time of purchase.

The customer will be deemed to have accepted the goods as being in accordance with its order unless it notifies Rick McLean's Designer Bathware of its claim within 14 days of receipt of the goods.

All returned goods will incur a 25% restocking fee on the total cost of goods.

The following conditions must be met however in order to accept returned goods:

- We have received prior notification by advising our office on 03 9331 6660 or in person
- Original tax invoice must be supplied
- Goods must still be in original condition
- Goods must still be in original packaging
- Customer is responsible for arranging return of goods and all transportation costs involved
- In the circumstance that a credit is issued, we will hold a credit for 30 days

Any goods authorised for return shall be returned at the customer's expense