












# Homelite®






## HBHT2655

**⚠ WARNING:** This procedure sheet is not a substitute for reading the operator's manual. To reduce the risk of injury, the user must read and understand the operator's manual before using the product.


### TO START A COLD ENGINE:

- ①  50:1 Ratio = Mix 20 mL of synthetic 2-stroke oil per litre of petrol. Ensure the fuel is fresh and is correctly mixed before pouring into the fuel tank.
- ②  Set the on/off switch to "I" position.
- ③  x10 Slowly press the primer bulb 10 times or until the fuel fills the bulb.
- ④  Set the choke lever to "full" choke position.
- ⑤  Squeeze the throttle lock and the throttle trigger.
- ⑥  Pull the starter grip and rope (4x maximum) until the engine attempts to start.
- ⑦  Set the choke lever to "half" choke position.
- ⑧  Squeeze the throttle lock and the throttle trigger.
- ⑨  Pull the starter grip and rope (6x maximum) until the engine starts.
- ⑩  Allow the engine to run for 10 seconds.
- ⑪  Set the choke lever to "run" position.

### TO START A WARM ENGINE:

- ①  Set the on/off switch to "I" position.
- ②  x10 Slowly press the primer bulb 10 times or until the fuel fills the bulb.
- ③  Set the choke lever to "run" position.
- ④  Squeeze the throttle lock and throttle trigger.
- ⑤  Pull the starter grip and rope (6x maximum) until the engine starts.

### TO STOP THE PRODUCT:

- ⑫  Set the on/off switch to the "Stop" position.

# QUICK START GUIDE

