INSTALLATION



Thoroughly clean glass using an ammonia-free cleaner, scraper & lint-free cloth. Measure area to be covered.




On a clean flat surface, cut decal 20-25mm wider than required on each side to ensure coverage.



PAPER
backing
exposing
adhesive
side
ensureing
frosted
decals
REMAIN ON
CLEAR SIDE
of film.

Peel away

NOTE: APPLICATION SOLUTION MAY BE REQUIRED TO ASSIST IN INSTALLATION



Pressing firmly apply adhesive side to glass in desired location. Rub out any creases or airbubbles. Gently peel away clear film layer.



Once backing film is removed, remove any remaining air bubbles pressing firmly with fingers. Once dry, wipe down with soft cloth.