

JOHNSTONE'S PROFESSIONAL CLEAR is a tough, clear, water based timber finish for use on internal and external window frames, doors and trims. Incorporating UV absorbers, it provides protection against the weather including the harmful effects of the sun's radiation. It has a low odour and unlike oil based coatings will not yellow. It can be applied over Johnstone's exterior oil colours and can be tinted to produce additional Johnstone's trend colours. Available in a Gloss and Satin finish.

AQUA PROTECT TECHNOLOGY:

Creates a highly durable barrier that repels water and resists mould, dirt and stains.

UV PROTECTION:

Protects against harmful UV rays.

WATER BASED:

Low odour, easy clean up.

FINISH:

Gloss and Satin.

IDEAL FOR:

Interior / exterior timber windows, doors and trims where a colourless clear coating is required.

SUITABLE SURFACES:

Interior / exterior soft and hard wood timber. Not suitable for coating areas subject to foot traffic or timber in constant sunlight.

FINISH:

Colourless Clear. Can be tinted to produce Johnstone's trend colours. When tinting clear, 2 coats must be applied to achieve selected colour. Colours will vary on different timber species. Available in both a Gloss and Satin finish.

COVERAGE:

Approx. 12m² per litre (dependent on porosity of the timber substrate).

SAFETY & FIRST AID

KEEP OUT OF REACH OF CHILDREN. Avoid skin and eye contact. Provide adequate ventilation. If using inside, keep windows and doors open during application and drying time.

IF SWALLOWED: Give plenty of water to drink. Seek medical advice.

EYE CONTACT: Rinse with plenty of running water. Seek medical advice if irritation occurs.

24 HOUR MEDICAL EMERGENCY RESPONSE SERVICE CALL:

AUSTRALIA: 1800 883 254
NEW ZEALAND: 0800 000 096



SURFACE PREPARATION

NEW EXTERIOR HARDWOOD TIMBER:

Allow the timber to naturally weather for 6 weeks. Alternatively, apply Johnstone's Professional Hardwood Tannin & Oil Remover followed by Johnstone's Professional Deck & Timber Cleaner following label instructions. Sanding of hardwood timber substrate prior to application of product is recommended, this will provide a key for the Johnstone's Professional Clear to adhere to.

SOFTWOOD TIMBER:

Ensure timber surface is clean and free from dirt and debris prior to application.

PREVIOUSLY PAINTED OR VARNISHED TIMBER:

Remove back to bare timber using Johnstone's Professional Timber Stripper, and / or sanding. For exterior surfaces clean with Johnstone's Professional Deck & Timber Cleaner following label instructions.

PREVIOUSLY STAINED AND OILED TIMBER:

For exterior surfaces, clean with Johnstone's Professional Deck & Timber Cleaner following label instructions. Rinse with water and allow to completely dry prior to application of Johnstone's Professional Clear. A light sand to the timber surface is recommended but not entirely necessary. Ensure timber is free from dirt, dust and contaminants prior to the application of Johnstone's Professional Clear.

WEATHERED AND GREY TIMBER:

For best results, sand timber back to fresh substrate. Clean with Johnstone's Professional Deck & Timber Cleaner following label instructions. Ensure surface is dirt and dust free prior to the application of Johnstone's Professional Clear.

TOUCH DRY:

30 minutes

RECOAT:

Allow a minimum of 1 hour between coats

APPLICATION

1. Stir thoroughly with a broad flat paddle before and during use.
2. Apply liberally to timber including exposed edges and end grain preferably by brush.
3. Apply two coats allowing 1 hour between the first and second coat. For increased durability and longevity, a third coat is recommended.

MAINTENANCE:

Re-apply as the timber changes colour or when water repellency diminishes due to weathering. Follow surface preparation instructions.

DRYING AND RECOAT TIME:

All timings quoted at 25°C and 50% humidity. Cooler or humid conditions may require longer.

IMPORTANT:

Do not apply this product in temperatures below 10°C or above 35°C or when heavy rain or dew is expected during the drying period. In hot temperatures, do not apply in direct sunlight. Attempt to coat when project is shaded.

CLEAN UP:

Clean brushes and equipment with water.

COVERAGE:

Approx. 12m² per litre.

PROTECT OUR ENVIRONMENT

Do not pour left over product down the drain. Unwanted product should be brushed out on newspaper allowed to dry then disposed of via domestic waste collections. Empty containers should be left open in a well ventilated area to dry out. When dry, recycle the container via steel can recycling programs. Disposal of empty containers via domestic recycling programs may differ between local authorities. Check with your local council first. For responsible disposal of product and packaging visit paintback.com.au (Australia only).

Further information:

AUS: www.johnstoneswoodcare.com.au

NZ: www.johnstoneswoodcare.co.nz