



## Fence Bracket Installation Guide

1. Slide the fence bracket (fin up) into the inner web of the steel post
2. Line up the pre-drilled holes from the fence bracket with the steel post
3. Use 2 x M12 bolts & nuts to fix them together
4. Tighten the nuts & bolts
5. Insert the top 2 rows of the concrete sleepers

**Helpful tip:** When installing the steel posts ensure you allow an extra 15-30mm spacing to have enough clearance for the bolts.

**Engineer note:** Depending on your soil conditions you may need to allow extra pier depth when putting a fence on top. As a guide, we recommend having an extra 400mm deeper pier when putting a standard 1.8m timber fence on top. If you are unsure consult an engineer or call