







#### **Products You Will Need**

Dulux Suede Effect, Metal Shimmer Effect or Stone Effect paint
Quality masking tape
A paint stirrer and drop sheet
Medium nap roller, roller tray and a 100mm paint brush

# **Preparation**

- Carefully read and follow the instructions on the product label before you begin.
- Mask off the area with painters tape where you don't want any paint, such as adjacent walls.
- Stir the paint well with a paint stirrer using an up and down scooping action. Make sure you scrape the bottom of the can to ensure particles are evenly distributed.
- Practice your application technique on a large, spare piece of board.

### **Application**

- Brush around the edges of the wall or the area you are painting.
- Apply the first base coat with the roller as you would normally paint.
  Allow drying time as specified on the label.
- Working in small sections, apply the second coat with the roller.
- While the paint is still wet apply a texture. Using a wide brush, dry roller or muslin, drag the paint in a random, overlapping pattern.

#### **Suggested Areas To Paint**

- **Dulux Suede Effect** feature walls in rooms such as bedrooms, studies and living rooms.
- Dulux Metal Shimmer Effect gates, fences, trim and decorative metal features.
- Dulux Stone Effect feature walls and architectural features.

## **Handy Tips**

- When painting, resist the temptation to touch up as you go as it will ruin the effect.
- Start in a top corner and work your way diagonally into the wall.

**Please note:** For further pre-preparation and application advice, see the How To Videos available at www.dulux.com.au





081.182