



BATH INSTALLATION INSTRUCTIONS – Freestanding models

Using a 40mm bath connector (FLEXIDINGER or equivalent), locate the elbow end to the pipe in the floor. Extend the flexible pipe through the waste opening in the bottom of the bath, and by manipulating the flexible pipe, fit the waste end to the bath waste hole or plug & waste as appropriate.

The bath should now be lowered into position to check the waste and flexible pipe location clearances are adequate and that there are no obstructions.

Once this has been determined, raise the bath and glue the elbow section making sure it is in the same position as tested (flexible pipe is pointed at the desired angle). The waste end should also be secured at this time.

The bath may now be lowered back into position and ready for sealing.

Using a waterproof/adhesive sealant (Sikaflex PRO11FC or equivalent) apply enough product to make a seal around the perimeter of the bath.

Using a 40mm DWV bath connector connected to the plug & waste, locate the pipe in the floor and measure the required length of pipe. This is to allow the tail of the bath connector to fit inside the pipe.