



PRO-200 WP

Below-ground

Waterproof membrane, for critical situations.

DESCRIPTION

Crommelin® PRO-200 WP is a premium, water based synthetic rubber, heavy duty waterproofing membrane for below ground and non-UV exposed applications.

Crommelin® PRO-200 WP is suitable for use in all below ground and non-UV exposed, critical applications, in situations associated with habitable areas such as retaining walls, landscape decks, green roofs, basements, lift shafts, planter boxes and water collecting tanks. Suitable for over-coating with renders, screeds or acrylic paints.

FEATURES AND BENEFITS

- Remains water tight under permanently wet conditions.
- Seamless application for leak free performance.
- Permanent flexibility and high elongation over 430%.
- Excellent substrate adhesion
- Primer less application (to well consolidated and dust free surfaces).
- Green Star - Design & As Built v1.1: Indoor Pollutants 13.1 Paints, Adhesives, Sealants and Carpets.
- APAS 181 – V.O.C limits.
- AS4020 Products for use with Drinking Water.

AREAS OF USE

PRO-200 WP is suitable for use in the following areas:

- Non-UV exposed Areas
- Plaza areas
- Planter boxes
- Basement car parks
- Landscape decks
- Retaining walls
- Lift shafts

SUITABLE SUBSTRATES

PRO-200 WP is suitable for use on the following surfaces:

- Concrete, masonry & cement renders.
- CFC sheeting and lightweight aggregate blocks.
- Timber & plywood sheeting.
- Steel – suitably prepared.

APPLICATION TOOLS

- Crommelin[®] Contractor Membrane Applicator Brush – 100mm, 75mm.
- Crommelin[®] Contractor Membrane Roller Cover – 230mm.

SURFACE PREPARATION

Full surface preparation instructions can be found at www.crommelin.com.au/full-instructions/

- Concrete must have cured for at least 28 days, screeds and renders 7 days.
- The surface should have a light even texture. Masonry should be flush pointed and all defects in existing surfaces made good.
- **Surfaces must be clean**, dry, sound and free from dust, grease, curing compounds, release agents, loose particles, efflorescence, concrete laitance or any other contaminants.
- Corroded metal should be wire brushed and treated with an anti-corrosion primer.
- All high points and protrusions should be removed, blow-holes and areas of honeycombing should be filled and the surface should be brought back to an even profile using a suitable repair mortar.
- **All surfaces must be dry.** A moisture test is required 100% of the time to ascertain if the substrate is dry enough to coat. Electronic moisture meters are recommended.
- If minor surface consolidation is required, apply 1 coat of 1:1 dilution of **PRO-200 WP** and water and allow to dry.
- If a greater amount of surface consolidation is required, apply one coat of **Crommelin[®] Powerflex** as per recommended application rates.
- If substrate is not dry, prime surface with **Crommelin[®] Dampstop** as per specifications.

PRODUCT PREPARATION

- **PRO-200 WP** is ready to use, simply stir well prior to application.

APPLICATION CONDITIONS

- Do not apply if surface/ambient temperatures are too high or too low. Recommended temperature range 7⁰c - 35⁰c.
- Do not apply if humidity is too high, or likely to be during the initial cure phase. Maximum recommended humidity during application and cure is 85%.
- Weather details may be checked at <http://www.bom.gov.au>.



APPLICATION PROCESS

Full application instructions can be found at www.crommelin.com.au/full-instructions/

- Bond breaking sealant/tape to all joints, junctions, protrusions, angles and internal corners must be used. The use of **Crommelin[®] Polyurethane Sealant**, **Crommelin[®] Silicone WP Plus** or **Crommelin[®] Reinforcing Fabric with Bond Breaker** is recommended.
- The use of **Crommelin[®] Reinforcing Fabric** is also recommended for use at all junctions to protect vulnerable areas from damage.
- Apply first coat evenly, as per recommended coverage rate and allow to dry.
- Re-coat when touch dry, after approximately 2-4 hours.
- Apply second coat evenly, at 90° (right angles) to first coat and allow to dry.
- Ensure membrane is protected from damage before backfilling.

RE-COAT/DRYING TIME @ 25°C / 50% RH

- Recoat time: 2- 4 hours.
- Full cure: 7 days.
- Ensure good airflow to optimise membrane cure time.

COVERAGE

- 1m² / L per coat – minimum 2 coats required.
- Wet film thickness: 1000 microns.
- Complex or highly irregular surfaces may require additional coats.

CLEAN UP

- Clean all equipment with water before product dries.
- Uncured material may be removed with warm water and detergent.

SIZES

PRO-200 WP is available in 15L pails.

- 15L produces 7.5m² of finished membrane.

RELATED PRODUCTS

- Crommelin[®] Moisture Meter.
- Crommelin[®] Contractor Membrane Applicator Brush – 100mm, 75mm.
- Crommelin[®] Contractor Membrane Roller Cover – 230mm.
- Crommelin[®] Dampstop.





PRECAUTIONS

- Ensure substrate is completely dry before application.
- Ensure adequate surface preparation is carried out to allow even application.
- Ensure a trial patch is applied to ensure suitability and desired result is achieved.
- Do not apply during periods of extreme weather conditions – temperature or humidity. Apply between 7⁰c and 35⁰c and less than 85% humidity. To check these conditions, refer to <http://www.bom.gov.au>

TRANSPORT AND STORAGE

- Size: 15L
- Weight: 19kg
- Cool and Dry Storage
- UN Number: N/A
- DG Class: N/A
- Flash Point: N/A
- Hazchem Code: N/A
- Poisons Schedule: N/A

PRODUCT APPEARANCE

- PRO-200 WP is black in colour.

SAFETY AND FIRST AID

Crommelin[®] PRO-200 WP Safety Data Sheet is available from Crommelin[®] upon request.

Safety

- Ensure good ventilation and avoid breathing vapours.
- Avoid skin and eye contact. Wear gloves and eye protection. Remove splashes on skin immediately and remove contaminated clothing.
- Keep out of reach of children.
- Keep container sealed when not in use.
- Do not swallow.

First Aid

- If poisoning occurs, contact a doctor or poisons information centre: Ph. 13 11 26.
- If swallowed, do not induce vomiting. Give a glass of water to drink.
- If in eyes, hold eyes open and flood with water for at least 15 minutes.
- If not breathing, apply artificial respiration.

Crommelin[®] and other marks followed by ® are registered trademarks.

Any advice, recommendation, information, assistance or service provided by Crommelin[®] in relation to its products or their use is given in good faith, however is provided without responsibility or liability.

Customers need to undertake their own assessment to determine the suitability of a product for the intended use. As the performance of any product is subject to a wide variety of different surface types as well as environmental and surface-specific conditions, it is essential that a sample of the product be applied to the intended area of use to ensure it is acceptable in appearance and finish and that it performs as required on the specific surface.

Crommelin[®] also reserves the right to update information without prior notice, to reflect ongoing research and product development.



7 Day Technical Support 1800 655 711

72 Division Street, Welshpool Western Australia 6106 T +61 8 9458 5711 F +61 8 9451 4749
service@crommelin.com.au www.crommelin.com.au