ONEGO™

Monier ONEGO™ is premixed all-in-one bedding mortar & flexible pointing system that was developed to simplify the process of ridge repair and replacement.



Monier ONEGO™ is an adhesive Mechanical Fastener for hip and ridge tiles developed in accordance with AS4046.8-2015 which requires all ridge and hip tiles to be fastened.

It has also passed the fatigue loading for Cyclonic Conditions C3 after conditioning by prolonged water saturation as per Australian Standard AS4046.8-2015. Once cured, Monier ONEGO™ forms an incredibly strong and durable bond between the tiles and the ridge. In order to achieve a BCA compliant ridge tile installation.

FFATURES:

Fast same day installation

No painting required

Replaces sand/cement bedding mortar

& pointing

Water clean up

Coverage: Approx 2-3 lineal metres

per 10L pail

WASH UP











AVAILABLE IN 4 COLOURS*









CAN BE USED ON BOTH CONCRETE AND TERRACOTTA RIDGE/ROOF TILES.

Coloured oxides can be added to ONEGO™ 'Neutral' to match any roof tile colour.

See Monier's ONEGO VIDEO



monier.com.au

HOW TO USE MONIER ONEGO™ ALL-IN-ONE AS A BEDDING MORTAR

Mix to a firm consistency for bedding tiles where more strength in the material is required.

STEP Mix



content.

Using a trowel mix the product until a slightly wet consistency is achieved. DO NOT over work/mix.



STEP Trowel ONEGO™ onto the roof tiles.

> Using a trowel place a 'sausage' shaped bed of ONEGO™ onto the surface of the roof tiles where the edges

of the ridge will be laid.



STEP Locate the ridge tile onto the ONEGO™ bedding.

> Push the ridge tile firmly onto the ONEGO[™] bedding material, ensuring it makes full contact.







HOW TO USE MONIER ONEGO™

AS A POINTING ADHESIVE

Mix to a smoother consistency for a smooth finish over the top of the bedding.

STEP Mix the product further to achieve a thinner consistency for pointing adhesive.

> DO NOT over mix or the product will be too thin to be applied as a pointing adhesive and may sag.



STEP Remove excess bedding material and apply pointing adhesive.

> Smooth off any excess pointing material, ensure the edge of the ridge tile is fully coated. You can mix ONEGO[™] to a 'wetter' consistency to fill any gaps or air holes.



^{*} Colours have been reproduced as faithfully as possible, however, actual colours may vary due to the printing process