

Homelite® Petrol Chainsaw

Quick Start Guide

HBCS3530/HCS3740

⚠ WARNING: This Quick Start Guide is not a substitute for reading the operator's manual. To reduce the risk of injury, the user must read and understand the operator's manual before using the product.

TO START A COLD ENGINE:

- ①  Turn the ignition switch to the "on" position.
- ②  Make sure the chain brake is in the "brake" position by pushing forward on the lever/hand guard.
- ③  Fully press and release the primer bulb at least 10 times.
- ④  Pull the choke lever all the way out to the "full-choke" position.
- ⑤  When the temperature is above 10°C, pull the starter grip until the engine attempts to start, but no more than 3 times. When the temperature is below 10°C, pull the starter grip until the engine attempts to start, but no more than 5 times.
- ⑥  Push the choke lever to the "half-choke" position.
- ⑦  Pull the starter grip until engine starts, but no more than 5 times. If the engine does not start, repeat steps 1 to 7.
- ⑧  Depress the trigger release and squeeze the throttle trigger, then release the throttle trigger to return the engine to idle.
- ⑨  Allow the product to run idle for 15 - 30 seconds.
- ⑩  Before accelerating the engine or cutting wood, make sure the chain brake is in the "run" position by pulling back on the brake lever/hand guard.

TO START A WARM ENGINE:

- ①  Turn the ignition switch to the "on" position.
- ②  Make sure the chain brake is in the "brake" position by pushing forward on the lever/hand guard.
- ③  Pull the choke lever all the way out to the "full-choke" position.
- ④  Push choke lever to the "half-choke" position.
- ⑤  Pull starter grip until engine runs, but no more than 5 times. If engine does not start after 5 pulls, use cold engine starting procedure.
- ⑥  Depress the trigger release and squeeze the throttle trigger, then release the throttle trigger to return the engine to idle.
- ⑦  Before accelerating the engine or cutting wood, make sure the chain brake is in the "run" position by pulling back on the brake lever/hand guard.

TO STOP THE PRODUCT:

- ①   To stop the engine, press the switch to the "stop" position.

