









# Homelite®





## HBLT25CNB/HLT25SDSN

**⚠ WARNING:** This procedure sheet is not a substitute for reading the operator's manual. To reduce the risk of injury, the user must read and understand the operator's manual before using the product.

### TO START A COLD ENGINE:


- ①  50:1 Ratio = Mix 20 mL of synthetic 2-stroke oil per litre of petrol. Ensure the fuel is fresh and is correctly mixed before pouring into the fuel tank.
- ②  Set on/off switch to "I" (On) position.
- ③  Slowly press the primer bulb 10 times or until the fuel fills the bulb.
- ④  Set the choke lever to full choke position.
- ⑤  For HBLT25CNB: Squeeze the throttle trigger completely and pull the starter grip until the engine attempts to start. Do not pull the starter handle more than 4 times.  
For HLT25SDSN: Squeeze the throttle lock and throttle trigger completely and pull the starter grip until the engine attempts to start. Do not pull the starter handle more than 4 times.
- ⑥  Set the choke lever to half choke position.
- ⑦  For HBLT25CNB: Squeeze the throttle trigger and pull the starter grip until the engine runs. Do not pull the starter grip more than 6 times.  
For HLT25SDSN: Squeeze the throttle lock and throttle trigger completely and pull the starter grip until the engine attempts to start. Do not pull the starter handle more than 6 times.
- ⑧  Allow the engine to warm for 10 seconds, then set the choke lever to run position.

### TO START A WARM ENGINE:

- ①  Set on/off switch to "I" (On) position.
- ②  Slowly press the primer bulb 10 times or until the fuel fills the bulb.
- ③  Set the choke lever to run position.
- ④  For HBLT25CNB: Squeeze the throttle trigger completely and pull the starter grip until the engine runs. Do not pull the starter grip more than 6 times.  
For HLT25SDSN: Squeeze the throttle lock and throttle trigger completely and pull the starter grip until the engine attempts to start. Do not pull the starter handle more than 6 times.

**NOTE:** If the engine does not start, return to step 2 under "To start a cold engine".

### TO STOP THE PRODUCT:

- ⑨  Push the on/off switch to the "O" (Off) position.

# QUICK START GUIDE

