

HANDYMAN Soldering Torch Kit with gas

PART NO. 211267

B

TO IGNITE / EXTINGUISH

Ensure the Safety Lock Switch is in the down position. Press the Ignition Button to ignite the flowing gas. To extinguish let go of the Ignition Button, if the Continuous Flame Switch has not been engaged. If the Continuous Flame Switch has been engaged, slide the switch forward to extinguish the flame. Adjust flame to the desired level using the Flame Adjust Slide.

ACTIVATING A CONTINUOUS FLAME :

Slide the Continuous Flame Switch backward while holding down the Ignition Button making sure that the torch has ignited before doing so. To disengage the continuous flame, slide the Continuous Flame Switch forward.

FILLING/REFILLING GAS:

Make sure torch is extinguished before filling and has cooled down. Hold the torch in an upside down position. Insert the butane canister refill nozzle into the refilling valve and push down. Stop refilling once the gas starts to overflow.

For use with TradeFlame Butane Gas Refill 60 g - Part No. 2312 or 200g - Part No. 2323

WARNING

To avoid injury or damage only ignite the torch when clear of face, hand, clothing or combustible materials. The burner/tip becomes extremely hot during and after operation, care must be taken to avoid accidental burns. Ensure flame is completely out after use. Do not expose to temperature above 50°C / 120F. Contains flammable gas under pressure, do not disassemble, puncture, drop or incinerate after use. Keep out of reach of children

