


ASSEMBLY INSTRUCTION FOR MAXI C16



! WARNING: Serious injury or death can be caused by toppling furniture

Help prevent tip-over:







- Anchor this product to a wall or other suitable surface
- Check anchors regularly
- Avoid placing TVs on top unless the TV is also anchored
- Use drawer locks to prevent children climbing










When attaching unit to wall put safety bracket in middle of unit with 16 Pan head screw then 25mm Pan head screw into wall.


For plasterboard without a stud it is recommended to use a plug with screw (not provided).

PARTS IDENTIFICATION LIST

2 x GABLES		1 x ADJUSTABLE SHELF	
1 x BACKING BOARD		1 x BOTTOM KICK	
3 x FIXED SHELF		1 x SAFETY BRACKET	

NO	MODEL	DESCRIPTION	QTY	NO	MODEL	DESCRIPTION	QTY
1		CONFIRMAT SCREWS	14	5		16 PAN HEAD SCREWS	1
2		WHITE CAPS	14	6		25mm PAN HEAD SCREWS	1
3		SUPPORT PINS	4	7		"L" SAFETY BRACKET	1
4		BACKING NAILS	40				

UNIT ASSEMBLY




INFILL

YOU WILL NEED TO RETRIEVE THE INFILL FROM PART 2, USING 3 X 30mm SCREWS PROVIDED, ATTACH THE INFILL TO THE UNDER-SIDE OF THE CAM SHELF BEFORE PUTTING YOUR SHELF INTO PLACE.



MULTISTORE

RUNNER POSITIONING



IMPORTANT


CABINET RUNNERS ARE MARKED AS FOLLOWS

C L = LEFT HAND SIDE
C R = RIGHT HAND SIDE

SEE DIAGRAM 2 BELOW

MAXI SERIES	
Models	Hole Positions
MAXI C16	1 – 8 – 15 – 20 – 25

RUNNER PLACEMENT



EG:- LEFT HAND SIDE RUNNER

DIAGRAM 2

Place metal runners in their correct hole positions (see above) making sure **CL = LEFT HAND GABLE & CR = RIGHT HAND GABLE**, then attach using the special 7.5mm euro screws provided (see diagram 1)

SEE DRAWER ASSEMBLY OVER



WARRANTY

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for major failure.

10 Year Warranty

- If the purchaser has a fault or defect with this product, the purchaser needs to contact Multistore Industries (Aust) directly on (07) 3208 6799 and state date of purchase, place of purchase and proof of purchase.
- Multistore Industries (Aust) will replace any faulty or defect parts at no cost to the customer. A replacement will be sent to you as soon as possible, or product can be exchanged at the store of purchase.
- This warranty is in addition to other rights and remedies of the customer under law.

Sincerely,

Multistore Industries (Aust) Management