

MICRO Blow Torch

PART NO. 211678

B

TO IGNITE

1. Push down on the Ignition Button (B)
2. To adjust the flame, use the Flame Adjustor Knob (C)

TO EXTINGUISH

1. Release the Ignition Button (B)
2. Close the Flame Nozzle Cover (A)

THIS PRODUCT IS SUPPLIED WITHOUT GAS. IT REQUIRES FILLING BEFORE USE.

FILLING/REFILLING GAS:

1. Ensure torch is not in operation and has cooled down.
2. Hold torch in an upside down position.
3. Insert the butane canister refill nozzle into the Refilling Valve and push down.
4. Stop refilling when gas starts to overflow.
5. DO NOT overfill. Let the gas settle, before trying to ignite

For use with TradeFlame Butane Gas Refill 60 g - Part No. 2312 or 200g - Part No. 2323

WARNING

To avoid injury or damage only ignite the torch when clear of face, hand, clothing or combustible materials. The burner/tip becomes extremely hot during and after operation, care must be taken to avoid accidental burns. Ensure flame is completely out after use. Do not expose to temperature above 50°C / 120F. Contains flammable gas under pressure, do not disassemble, puncture, drop or incinerate after use. Do not attempt to repair this item. Do not use for more than 5 minutes at one time. Keep out of reach of children.

