


3x3M ANDAMAN CANTILEVER UMBRELLA

Assembly Instructions Item No. 3192542





Please carefully read the below warnings and instructions. Save the instructions for future reference.

- 1.Please carefully read all instructions before assembly and use
- 2.Please separate and identify all parts, ensuring that you have all parts listed
- 3.To avoid damaging your umbrella, it is recommended that you assemble it on a clean, protected surface
- 4. Washers must be used when indicated during the assembly process
- 5.Loosely tighten the nuts and then securely tighten when all are in position. Be careful not to over tighten the nuts during assembly.


	PARTS LIST	
CODE	PARTS	QTY.
Α	Frame & Canopy	1PC
В	Plastic Base	1PC
С	Housing Cover	1PC
D	Square Tube	1PC
E	Rotary Knob	1PC
F	Stay Pole	1PC
G	Umbrella Cover	1PC
Н	crank	1PC

HARDWARE LIST			
CODE	PARTS	QTY.	
I	Screw & Washer	4PCS	
J	Allen Key	1PC	


Assembling Instruction




1 Fix the square tube (D) with the plastic base (B) using screw & washer (I).



2 Place the plastic circle (C) onto umbrella base pole.




3 Fill the base with water or sand to make it stable.




ATTENTION: The base needs to be secured with water or sand to help keep the umbrella stable.

Place the frame & canopy (A) onto the umbrella base pole, using rotary knob (E) to fix.










HOW TO OPEN AND

Squeeze the handle and push it in the upwards direction towards the top of the umbrella pole until it locks into place.











Click to tilt umbrella angle as you like (approx 90 degree of each side).






HOW TO RELOCATE YOUR UMBRELLA






Now that the handle and wheels are fully extended, the umbrella base can be easily pulled to your new location


Do not attempt to pull your umbrella up a steep slope or grassed surface.








Once the umbrella base is in the desired location, wind up the cord and handle and store in base. Retract the wheels by winding the handle in an anti-clockwise direction.




MIMOSA° THE SIGNATURE COLLECTION

Operating Instruction

HOW TO CLOSE THE UMBRELLA




Close the total frame & canopy by moving the crank downwards to the lowest position hole.







16




Lift the umbrella cover (G) to the top of the umbrella using the stay pole (F). Pull the umbrella cover (G) down over the umbrella with your hands.









Once it has fully covered the umbrella, pull the zip closed and put the stay pole in the protective bag.



ATTENTION: DO NOT use in extreme weather conditions including high wind and heavy rain.





CARE AND CLEANING:

- 1. To clean, wipe with damp cloth. Do not use bleach, acid solvents or abrasive cleaners.
- 2. During winter or periods of heavy rain and wind, it is strongly recommended that the umbrella be stored in its cover, in a dry protected area.