



# STORAGE STATION 2090H x 1820W x 540Dmm

ITEM NO: GOSO97

**Very Important:** Unpack the unit and confirm that you have all the parts listed. Assemble the unit on a solid, level surface. Avoid carpet. You will need the assistance of a second person during assembly. **Safety tip:** For added safety and support we recommend you fix unit to a wall. **You will need the following:** Rubber mallet, Phillips head screwdriver, adjustable spanner and 3mm drillbit.







SERIOUS INJURY OR DEATH CAN BE CAUSED BY TOPPLING FURNITURE

#### TO HELP PREVENT A TIP-OVER:


 Anchor this product to a wall or other suitable surface with th provided "Tip over prevention kit", "Check anchors regularly

FOR MORE INFORMATION SEARCH: www.productsafety.gov.au


### ▲ SAFETY TIP:

When assembling or installing this product wear protective gloves and eyewear.


**NOTE:** This product has been tested to safely carry a load of up to 2500kg evenly distributed, when properly installed and maintained. Heaviest items to be loaded on lowest shelves.




(refer to last page for installation).




Step 1: Add Foot End Caps to bottom of Legs 'D'. Slot Brackets 'A' into the bottom of Legs 'D' as shown in the diagram. NOTE: Flat edges face outwards. Lock rivets to the bottom of the keyhole by tapping the Brackets with a rubber mallet.




**Step 2:** Slot Brackets 'B' into the bottom of Legs 'D' as shown in the diagram. Slot Braces 'C' into position through the holes provided on Brackets 'A'. NOTE: Flat edges face outwards. Lock rivets to the bottom of the keyhole by tapping the Brackets with a rubber mallet.




**Step 3:** Assemble the benchtop frame by slotting brackets A and B followed by braces 'C'. **Please note:** All brackets for this step need to be slotted into the 25th and 26th keyhole from the bottom of part 'D' (legs).




**Step 4:** Repeat Steps 1 and 2 for the middle shelf. Lay the wire shelf and Timber Benchtop 'E' between brackets as shown in the diagram.



Step 5: Slot Bottom Pegboard 'F' and Top Pegboard 'G' into the keyholes above the benchtop as shown in the diagram. Secure the two pices of pegboard together in the middle with the provided bolts 'H' and nuts 'J' and then fasten the bottom pegobard to the timber benchtop using the M5 x 16mm Self Tapping Screws 'K' provided. Please note when fixing the bottom pegboard to the timber benchtop it is recommended that you drill a pilot hole using a 3mm drill bit.



**Step 6:** Slot in Bracket 'A' and Brackets 'B' into the top of Legs 'D' as shown in the diagram. Slot Braces 'C' into position through the holes provided. NOTE: Flat edges face outwards. Lock rivets to the bottom of the keyhole by tapping the Brackets with a rubber mallet.



Step 7: Lay the wire shelf between brackets as shown.

**PLEASE NOTE:** Refer to next page for attaching the provided Tip-over prevention kit.


WARRANTY CONDTIONS: Any claim under this warranty must be made within 1 year of the date of purchase of the product. To make a claim under this warranty, take the product (with proof of purchase) to any Bunnings store (see www.bunnings.com.au for store locations). Pinnacle Hardware bears reasonable, direct expenses of claiming under the warranty. You may submit details and proof of purchase to our support centre for consideration. The warranty covers manufacturer defects in materials, workmanship and finish under normal use. This warranty is provided in addition to other rights and remedies you may have under law: Our goods come with guarantees that cannot be excluded under the Australian consumer law or Consumer Guarantees Act 1993 (NZ). You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This warranty excludes damage resulting from product misuse or product neglect, any modifications, additions or alterations to the product including the addition of extra shelves. Additions or modifications can compromise the structure and safety of the product. The warranty covers domestic use only and does not apply to commercial applications. This warranty is given by Pinnacle Hardware, ABN 87 614 496 196, 28 Hudson Court, Keysborough Vic 3173, 1800 349 776, Email: support@pinnacle.net.au. New Zealand customers please contact HARCO (Harkness & Young Ltd), Email: sales@harknessyoung.co.nz. 'Pinnacle' is a trademark. @ Pinnacle Hardware. Suitable for model number GOSO97.




## TIP OVER PREVENTION KIT:

**PLEASE NOTE:** We strongly recommend that this product is permanently fixed to a wall. Please use the provided "Tip over prevention kit" to securely fix product to your wall.







### It is STRONGLY RECOMMENDED that you ANCHOR this product.

Toppling furniture can cause serious injuries and death.

A "Tip over prevention kit" has been provided with this product to stop your furniture from tipping forward, it is strongly recommended that you **securely attach this product** to a wall or other solid surface using the provided fixings.

**IMPORTANT:** Regularly check that anchors are securely maintained. Stability of tall items may be affected by thick pile carpet or uneven floors.

#### **CAUTION:**

For your safety when attaching the anchor fixings, please note the following:

- Check for any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson)
- Walls are constructed from different materials, for example, masonry (solid brick) or plasterboard lined cavity walls (hollow). It is important that you use the appropriate wall fixings for your wall type.