# **Seating & TV Position**

## Ideal Position

To enable you to fully enjoy the TV programs and Movies you should do the following:

- 1. Place your TV on a central flat wall.
- 2. Place the centre of the screen at eye level.
- 3. Sit about 1 metre for every 10" of screen size away.



### Screen Glare

To avoid Screen glare you should:

- 1. Try to position your TV on an internal wall which hasn't got windows directly opposite.
- 2. Or use a tilting TV bracket with at least 5 degrees of tilt as this eliminates any glare.

## Bracket Choice

To enable the correct choice

- 1. Check your TV's owner manual for mounting guidelines.
- 2. Check to see if it has specific vesa mounting patterns.
- 3. Select the correct bracket based on vesa mounting holes on your TV.

## VESA Standard

If your TV is VESA compatible all it means is that the fixing holes in the rear of the set conform to an agreed pattern of sizes. These are in millimeters and cover the distance apart of the holes in firstly horizontal plain, then in vertical.

# Easy Step by Step Installation Process



Decide on the best location in the room.

Step



Check the wall for studs or a secure mounting position and mount the wall plate ensuring it is level with a spirit level or built in bubble level.



Fix the front plate to the back of the TV ensuring the holes line up with the Vesa mounts.

Step



Slide the TV onto the wall plate and screw the locking screw.

\* Full instructions are included in all our products detailing the Do's and Don'ts of installation.

#### Recommended tools:

- Screwdriver
- Stud Finder
- Cordless/Electric Drill
- Spirit Level if Needed









Masterplug Pty Ltd Australia & NZ Office:

Noosa Boardroom, Noosa Civic Commercial Eenie Creek Road (PO Box 1613) Noosaville QLD 4566 AUSTRALIA

**Helpline number:** 1300 734 714 **Email:** robert.smith@masterplug.com.au




TV WALL MOUNT **SELECTION GUIDE** 



# How to Choose the right Bracket for you

- 1. Think about where the TV will go on the wall. If it is directly in front of where you want to be sitting and you don't want to move the TV then you probably only need a basic Flat TV bracket so we would suggest the Low Profile or Fixed versions from the chart opposite.
- 2. If your TV is going to be mounted higher on the wall than your eye-line then you'll need the tilting type of TV bracket which as it says, allows you to tilt the TV so it can be in line with your vision and that way you will get the optimum picture.
- 3. If you want to fit the TV into a corner or you need to move it out off the wall so it reaches out into the room choose a Full Motion TV bracket. These are the most flexible wall mount brackets although they are often heavy to safely support your valuable TV.
- 4. Match the size of your TV to the TV bracket, these are clearly detailed on our packaging and on the table opposite so you can make your selection even easier.
- 5. Lastly as a double check the VESA mounting holes in your TV's instruction booklet or measure the width apart of the fixing holes on the rear of your TV and ensure they are less than the maximum width the particular TV bracket can accommodate.



Be careful to choose a bracket which covers the Vesa Mounting holes

## **UNDERSTAND OUR ICONS**



#### **SCREEN SIZE**

An indication of the screen sizes our mounts accommodate but please check your TV's vesa mounts dimensions for complete compatibility.



#### **MAX WEIGHT**

All of our mounts are independently tested to ensure they can hold your TV with no problems.



Kitchen Brackets

flip-down mount

### **VESA**

Indicates the maximum vesa sizes the mount can hold. Generally our mounts start at Vesa 75 x 75



On the following models: LRT400, LRT600, LRT800, LPSRFS400

Spirit Level built in for ease of installation: