


WALL MOUNTED CABINET 600H x 600W x 250Dmm ITEM NO: GOSO21

Very Important: Unpack the unit and confirm that you have all the parts listed. Assemble the unit on a solid, level surface. Avoid carpet. You will need the assistance of a second person during assembly. **Safety tip:** For added safety and support we recommend you fix unit to a wall. **You will need the following:** Rubber mallet, Phillips-head screwdriver and adjustable spanner.







When assembling or installing this product wear protective gloves and eyewear.


NO	PART NAME	PCS
A	Top panel	1PC
В	Left side panel	1PC
C	Right side panel	1PC
D	Back panel	1PC
E	Bottom panel	1PC
F	Shelf	1PC
G	Door	1PC
H	Shelf support	4PCS
J	Self-tapping screw (8g x 10mm)	14PCS
K	Hinge pin	2PCS
Ĺ	Phillips-head bolt (M6 x 10mm)	4PCS
M	Hex nut (M6)	4PCS
N	Self-tapping screw (10g x 32mm)	4PCS
0	Plug	4PCS
P	Washer	4PCS

This unit may have sharp edges. Please use gloves when assembling.







Step2: Slide back panel (D) into bottom panel (E) ensuring tabs on back panel insert into slots in bottom panel. Then attach back panel (D) to side panels (B & C) using self tapping screws (J) as per the diagram above.




have been inserted, fix all panels together using self tapping screws (J) as per diagram above. Install shelf supports (H) into slots in all four corners at an even height and insert shelf (F).



Step 4: Install door (G) by aligning door hinge slots with those on right side panel (C) and insert hinge pins (K).



Step 5: This cabinet can be easily mounted onto a peg board (see Pinnacle Hardware item GOS025 from our Garage Storage System) using the included Phillips-head bolts (L) and hex nuts (M) as shown in the diagram above.



Alternatively, the cabinet can be mounted onto a wall. First, drill four holes which align exactly with the holes in the back panel for mounting the cabinet. Then insert the included plugs (O) into the holes and use the long self tapping screws (N) and washers (P) to attach the cabinet to the wall.

WARRANTY CONDITIONS Any claim under this warranty must be made within 1 year of the date of purchase of the product. To make a claim under this warranty, take the product (with proof of purchase) to any Bunnings store (see www.bunnings.com.au for store locations). Pinnacle Hardware bears reasonable, direct expenses of claiming under the warranty. You may submit details and proof of purchase) to any Bunnings store (see consideration. The warranty covers manufacturer defects in materials, workmanship and finish under normal use. This warranty is provided in addition to other rights and remedies you may have under law: Our goods come with guarantees that cannot be excluded under the Australian consumer law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably excludes damage resulting from product misuse or product neglect. The warranty covers domestic use only and does not apply to commercial applications. This warranty is given by Pinnacle Hardware, ABN 87 614 496 196, 28 Hudson Court, Keysborough Vic 3173, 1800 349 776, Email: support@pinnacle.net.au. New Zealand customers please context HARCO (Harkness & Young Ltd), 09 27 64071, Emails endemotionest comparison product messative defendements and the daware, Suitable for model humber GDS021 Email: sales@harknessyoung.co.nz. 'Pinnacle' is a trademark. © Pinnacle Hardware. Suitable for model number GOSO21.

OR