

✓ CONFIGURATION GUIDE
INSIDE WINDOW FRAME (REVEAL FIT) ONLY

Adjustable Range **20mm**
(Horizontal & Vertical)

EasyAS Shutters can be adjusted up to 20mm horizontally (width) and vertically (height).

P = No. of Panels

M = No. of Mid Rails (the horizontal divider within a panel)

If a mid rail is required it will be placed at 600mm from the base. If a second mid rail is required it will be placed midway between the first mid rail and the top of the frame.

THE LAYOUT OF YOUR SHUTTER WILL BE BASED ON THE FOLLOWING TABLE AND DIMENSIONS OF YOUR WINDOW OPENING

		WIDTH (mm)			
		410 - 910 1x Panel	910 - 1610 2x Panels	1610 - 2810 4x Panels	2810 - 3500 6x Panels
HEIGHT (mm)	Window Opening Range 400 - 1490 0x Mid Rail				
		P1-M0	P2-M0	P4-M0	P6-M0
	1490 - 2200 1x Mid Rail				
		P1-M1	P2-M1	P4-M1	P6-M1
	2200 - 2850 2x Mid Rail				
		P1-M2	P2-M2	P4-M2	P6-M2