

















wood screws x 2

# wood screws x 14

# attaching push to open

mechanism


and catch

# Identifying the location of the push to open mechanism

Depending on the type of cabinet, the location of the Push to Open mechanism will vary.

# attaching push to open mechanism and catch

# base cabinets wall cabinets top side of support rail bottom panel sits on top of bottom panel front of cabinet front of cabinet push to open mechanism push to open mechanism



### Caring for your Kaboodle parts and accessories


Looking after your parts and accessories is really easy and with the right care and maintenance they will last you for many years. Just follow these simple steps.

Hinges, runners and other parts and accessories should be kept dry at all times. To keep the mechanisms performing at their best, regularly wipe them with a dry cloth removing any dust and grime that may build up. In case of spills, clean immediately with a dry cloth. Do not use harsh abrasives.

If you need any more information you can contact us: Australia: **1800 666 078** Monday to Friday between 8:00am and 6:00pm AEST. New Zealand: **0800 522 663** Monday to Friday between 8:00am and 5:00pm NZST or email: info@kaboodlegroup.com.au.




# for installation in single door cabinets




underside of support rail side panel

pre-drill holes and use the 22mm screws to attach the mechanism.









# removing hinge plate

remove the hinge from the hinge plate by pushing on the release tab.



## attaching push to open mechanism and catch attaching hinge plate to cabinet attaching hinge to door



note: screw through

