



6 TIER ADJUSTABLE SHELF

2090H x 1500W x 540Dmm POWDER COATED


Very Important!


Unpack the unit and confirm that you have all the parts listed. Assemble the unit on a solid level surface, avoid carpet. You will need the assistance of a second person during assembly. You will need the following: Rubber Mallet or Hammer.

Note: Do not place additional MDF boards on shelving brackets until completion of shelving unit!


A SAFETY TIP:

When assembling or installing this product wear protective gloves and eyewear.






Place foot caps onto the bottom of the 4 legs 'F'. Note upright position. Place shelving bracket 'C' onto the legs 'F'. A rubber mallet can be used to lightly tap all brackets into the keyholes of the legs into place. Allow one keyhole free between the foot cap and the shelving bracket.




Use shelf bracket 'D' for the side brackets using the shelf bracket from Step 1 as a guide for height. Allow 1 keyhole free from the ground as shown in the diagram. Use same shelving brackets for opposing sides as shown in the diagram. Place brace 'E' as shown.




Place MDF board on bottom shelf to minimise buckling. Join the upper legs to the lower legs with the connector pins.


Note: The legs are designed to sit directly on top of each other – don't overlap them. Handy Hint: Flathead screwdriver may be used to tap in connector pins.




Join the top rivets of the connector plates to the bottom keyholes of the upper legs and bottom rivets of the connector plates to the top keyholes of the lower legs. Gently tap the connector plates in place with a mallet and a screw driver on the notch.



Fix brackets 'C' at the very top allowing room for the MDF board to sit flush against the legs. Repeat with brackets 'D'.



Apply remaining brackets as above to desired height. Ensure that braces 'E' are fixed to all shelves.



Place the MDF boards in the shelves. Ensure that they are sitting flush against the edge of the shelf brackets.

WARRANTY CONDITIONS

WARRANTY CONDITIONS
Any claim under this warranty must be made within 1 year of the date of purchase of the product. To make a claim under the warranty, take the product (with proof of purchase) to any Bunnings store (see www.bunnings.com.au for store locations). Romak Hardware Distributors Pty Ltd bears reasonable, direct, expenses of claiming under the warranty, brownided in addition to other rights and remedies you may have under law: our goods come with guarantees which cannot be excluded under the Australian Consumer Law. You are entitled to replacement or refund for a major failure and compensation for other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The warranty excludes damage resulting from product misuse or product neglect. The warranty covers domestic use only (fairnness & Young Ltd), 2 2 7 64071, Email: sales@formak.com.au. New Zealand customers please contact HARCO (Harkness & Young Ltd), 2 2 7 64071, Email: sales@formak.com.au. New Zealand customers please contact HARCO