

attaching corner cabinet hinges to a door

Caring for your Kaboodle parts and accessories

Looking after your parts and accessories is really easy and with the right care and maintenance they will last you for many years. Just follow these simple steps.

Hinges, runners and other parts and accessories should be kept dry at all times. To keep the mechanisms performing at their best, regularly wipe them with a dry cloth removing any dust and grime that may build up. In case of spills, clean immediately with a dry cloth. Do not use harsh abrasives.

If you need any more information you can contact us: Australia: **1800 666 078** Monday to Friday between 8:00am and 6:00pm AEST. New Zealand: **0800 522 663** Monday to Friday between 8:00am and 5:00pm NZST or email: info@kaboodlegroup.com.au.


| | | |
|---|---|---|
| A  135° hinges x 2 | B  165° hinges x 3 | C  14mm wood screws x 30 |
|---|---|---|

attaching corner cabinet hinges to a door

removing hinge plate

1.

remove the hinge from the hinge plate by pushing on the release tab.




attaching hinge plate to cabinet

2.


attach screws through the elongated holes.

note: The elongated holes on the hinge plate face the rear of the cabinet and the round holes face the front.




attaching hinge to 1st door

3.



attaching hinge to 2nd door

4.



attaching the two door panels together

5.

