

# 5 TIER ADJUSTABLE CORNER SHELF

# 1830H x 730W x 730Dmm POWDER COATED


#### **Very Important!**


Unpack the unit and confirm that you have all the parts listed. Assemble the unit on a solid level surface, avoid carpet. You will need the assistance of a second person during assembly. You will need the following: Rubber Mallet or Hammer.

Note: Do not place additional MDF boards on shelving brackets until completion of shelving unit!


# **A** SAFETY TIP

When assembling or installing this product wear protective gloves and eyewear.






Place foot end caps onto the bottom of the 5 legs 'H' and 'l'. Note upright position. Place shelving bracket 'A' onto the legs. A rubber mallet can be used to lightly tap all brackets into the keyholes of the legs into place. Allow one keyhole free between the foot cap and the shelving bracket.




Use two shelf brackets 'B' for the side brackets using the shelf bracket from Step 1 as a guide for height, followed by shelf bracket 'E' as shown in the diagram. Place brace 'G' as shown.




Join the upper and lower legs with the connector pins, as shown in the diagram, taking into account upright position. Note: The legs are designed to sit directly on top of each other – don't overlap them. Handy Hint: Flathead screwdriver may be used to tap in connector pins.

#### Step 4




Fix brackets 'A' so that the top rivet sits on the upper legs and the bottom rivets sit on the lower legs. Repeat with brackets 'B' and 'E', followed by brace 'G' as done previously.

## Step 5




Fix brackets 'C', 'D' and 'F' at the very top allowing room for the MDF board to sit flush against the legs. Repeat as per previous step.

## Step 6



Apply remaining brackets as above to desired height. Ensure that brace 'G' are fixed to all shelves.

## Step 7



Place the MDF boards in the shelves. Ensure that they are sitting flush against the edge of the shelf brackets.

#### WARRANTY CONDITION

WARRANTY CONDITIONS
Any claim under this warranty must be made within 1 year of the date of purchase of the product. To make a claim under the warranty, take the product (with proof of purchase) to any Bunnings store (see www.bunnings.com.au for store locations). Romak Hardware Distributors Pty Ltd bears reasonable, direct, expenses of claiming under the warranty, tow may submit details and proof to our store for consideration. The warranty covers manufacturer defects in materials, workmanship and limits under normal use. This warranty is provided in addition to other rights and remedies by our may have under law: our goods come with guarantees which cannot be excluded under the Australian Consumer Law. You are entitled to replacement or refund for a major failure and compensation for other reasonably foreseeable loss or damage, You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The warranty excludes damage resulting from product misuse or product neglect. The warranty covers domestic use only and does not apply to commercial applications. This warranty is given by Romak Hardware Distributors Pty Ltd, ABN 15489950457, 177-181 Atlantic Drive, Keysborough Vic 3173, (03) 9795-6789, E-mail: sales@romak.com.au. New Zealand customers please contact HARCO (Harkness & Young Ltd), 9 27 64071, Email: sales@romak.com.au. New Zealand customers please contact