

SPECIFICATIONS

Battery: Detection Depth:

Weight:

9V DC Battery 19mm (Wood, Metal) 50mm (Ferrous Metal) 38mm (Copper) 50mm (Live Wires) 135a

ozito.com.au



WHAT'S IN THE BOX



Stud Detector



9V Battery

🕖 YEAR REPLACEMENT WARRANTY

SDR-050

WARRANTY

IN ORDER TO MAKE A CLAIM UNDER THIS WARRANTY YOU MUST RETURN THE PRODUCT TO YOUR NEAREST BUNNINGS WAREHOUSE WITH YOUR BUNNINGS REGISTER RECEIPT. PRIOR TO RETURNING YOUR PRODUCT FOR WARRANTY PLEASE TELEPHONE OUR CUSTOMER SERVICE HELPLINE:

Australia 1800 069 486 New Zealand 0508 069 486

TO ENSURE A SPEEDY RESPONSE PLEASE HAVE THE MODEL NUMBER AND DATE OF PURCHASE AVAILABLE. A CUSTOMER SERVICE REPRESENTATIVE WILL TAKE YOUR CALL AND ANSWER ANY QUESTIONS YOU MAY HAVE RELATING TO THE WARRANTY POLICY OR PROCEDURE. The benefits provided under this warranty are in addition to other rights and remedies which are available to you at law.

Our goods come with guarantees that cannot be excluded at law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Generally you will be responsible for all costs associated with a claim under this warranty, however, where you have suffered any additional direct loss as a result of a defective product you may be able to claim such expenses by contacting our customer service helpline above.

3 YEAR REPLACEMENT WARRANTY

Your product is guaranteed for a period of **36 months from the** original date of purchase and is intended for DIY (Do It Yourself) use only. If a product is defective it will be replaced in accordance with the terms of this warranty. Lithium Ion batteries are covered by a **12 month warranty**. Warranty excludes consumable parts.

WARNING

The following actions will result in the warranty being void.

- If the tool has been operated on a supply voltage other than that specified on the tool.
- If the tool shows signs of damage or defects caused by or resulting from abuse, accidents or alterations.
- Failure to perform maintenance as set out within the instruction manual.
- If the tool is disassembled or tampered with in any way.

KNOW YOUR PRODUCT

STUD DETECTOR

- 1 Digital Display
- 2 Mode Buttons
- 3 On/Off Button4 Detection Button
- 1 2 3 4

ACCESSORIES

5 Battery 9V



ONLINE MANUAL

Scan this QR Code with your mobile device to take you to the online manual.



SETUP & PREPARATION

1. INSTALLING BATTERIES

The Stud Detector unit requires a 9V battery to operate.

1 Remove the battery compartment lid from the back of the unit using the tab at the top.



2 Attach the 9V battery to the battery clip in the correct direction so that it clicks into place.



3 Place the bottom of the battery lid into the recess in the unit and push the lid tab down to secure in place.



YEAR REPLACEMENT WARRANTY

OPERATION

2. CONTROLS

Switching On and Off

- 1 To turn the unit on, press the on/off Button
- 2 To turn the unit off, press the on/off button again.

Note: The unit will automatically turn off after 60 seconds of inactivity.



STUD METAL DEEP AC

(ľ)

19mm

19mm

 \triangleright

Mode Selection

The directional mode buttons allows you to select between the 4 operational modes.

Note: An arrow is displayed at the bottom of the digital display, indicating the current mode.

Stud detection mode:

For metallic and non-metallic materials (wood, metal, etc.)

- Wood max. detection depth:
- · Metal max. detection depth:

Metal detection mode:

For ferrous materials and copper piping	
 Ferrous Metal max. detection depth: 	50mm
Copper max. detection depth:	24mm
Deen detection mode:	

conner nining metal wood F

or copper piping, metal, wood	
 Wood max. detection depth: 	19mm
Metal max. detection depth:	38mm
Copper max. detection depth:	38mm

AC detection mode:

For live cables (power cords, network cables, etc.)

• Max. detection depth: 50mm

Detection Button

1 The detection button is used to calibrate and start detecting objects.



3. CALIBRATION

The stud detector needs to be calibrated for the characteristics of the search area before each measurement.

Note: Calibrations needs to be repeated every 60 seconds in order to reduce the occurrence of measuring errors.

1 Turn the unit on by pressing the on/off button.



2 Hold the back of the stud detector against the surface.



- 3 Select an area of the surface that is less likely of finding the material you are trying to locate.
- 4 Press and hold the detection button to allow the detector to calibrate correctly. The calibration is complete when you hear 3 beeps.





4. OPERATION

1 Turn the unit on by pressing the on/off button and complete the calibration instructions in the previous section.



 \triangleleft

U

 \triangleright

- 2 Once the calibration is complete (indicated by 3 beeps), continue to hold the detection button down.
- 3 Move the unit slowly in a horizontal direction along the surface.
- 4 If you get close to the search object, bars will start to appear on the digital display.
- 5 Continue to move the unit slowly until all bars on the display are filled. Mark this position on the wall.





6 Once this position has been marked, the detection button can be released.



Repeat this process in the opposite horizontal direction and make a second mark. These marks indicate the edges of the object.
 Note: The middle of these marks indicates the centre of the object.



SDR-050

MAINTENANCE

- When not in use, the tool should be stored in a dry, frost free location, keep out of children's reach.
- If the housing of the tool requires cleaning, do not use solvents but cloth only.

Note: Ozito Industries will not be responsible for any damage or injuries caused by repair of the tool by an unauthorised person or by mishandling of the tool.

TROUBLESHOOTING

Stud detector does not turn on

The batteries may be depleted. Ensure you have inserted a 9V battery with a full charge.

Make sure the battery terminals are connected in the correct direction.

Digital display does not show any bars

The stud detector must be calibrated correctly and then the detection button continued to be held down while moving the unit along the wall or surface.

DESCRIPTION OF SYMBOLS

V	Volts	W	Watts
dc/ 	Direct current	8	Read instruction manual
mW	Milliwatt		Regulatory Compliance Mark (RCM)
	Warning	凸	Indoor use only
	Laser Light Laser Radiation	X	Do not put in the rubbish

CARING FOR THE ENVIRONMENT



Power tools that are no longer usable should not be disposed of with household waste but in an environmentally friendly way. Please recycle where facilities exist. Check with your local council authority for recycling advice.

Re Re Ple col

Recycling packaging reduces the need for landfill and raw materials. Reuse of recycled material decreases pollution in the environment. Please recycle packaging where facilities exist. Check with your local council authority for recycling advice.

GENERAL POWER TOOL SAFETY WARNINGS

WARNING! Read all safety warnings and all instructions. Failure to follow the warnings and

- instructions may result in electric shock, fire and/or serious injury. Save all warnings and instructions for future reference. The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool. 1. Work area safety
- Keep work area clean and well lit. Cluttered or dark areas invite accidents
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes. b.
- c. Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control

2. Electrical safety

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded. h c. Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the
- risk of electric shock. d. Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase
- the risk of electric shock When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a e.
- cord suitable for outdoor use reduces the risk of electric shock. If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) f. protected supply. Use of an RCD reduces the risk of electric shock.
- 3. Personal safety
- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
- Use personal protective equipment. Always wear eye protection. Protective equipment such as dust b. mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power c. source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury. d.
- Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations. e

- Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
- If devices are provided for the connection of dust extraction and collection facilities, ensure these g. are connected and properly used. Use of dust collection can reduce dust-related hazards 4. Power tool use and care
- Do not force the power tool. Use the correct power tool for your application. The correct power tool a. will do the job better and safer at the rate for which it was designed
- Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be b. controlled with the switch is dangerous and must be repaired.
- Disconnect the plug from the power source and/or the battery pack from the power tool before c making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users
- Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking q. into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
- 5. Battery tool use and care
- Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack
- Use power tools only with specifically designated battery packs. Use of any other battery packs may b. create a risk of injury and fire. When battery pack is not in use, keep it away from other metal objects, like paper clips, coins,
- C. keys, nails, screws or other small metal objects, that can make a connection from one terminal to another. Shorting the battery terminals together may cause burns or a fire. Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact
- d. accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.
- 6. Service Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained

BATTERY SAFETY WARNINGS

THIS MANUAL CONTAINS IMPORTANT SAFETY AND OPERATING INSTRUCTIONS FOR YOUR TOOL AND BATTERY

- DO NOT store or use the tool and battery pack in locations where the temperature may reach or exceed 40°C (such as inside sheds or metal buildings in summer).
- Do not incinerate the battery pack even if it is seriously damaged or is completely worn out. The battery can explode in a fire

SPARE PARTS

Spare parts can be ordered from the Special Orders Desk at your local Bunnings Warehouse.

For further information, or any parts not listed here, visit www.ozito.com.au or contact Ozito Customer Service:

Australia 1800 069 486

New Zealand 0508 069 486

E-mail: enquiries@ozito.com.au