



# The Grange

## User's Guide

# Thank you for choosing The Grange by dormakaba

This guide will assist in using the features and functions of the lock.


Please download the app dormakaba The Grange from the App store or Google Play. Or scan QR codes found on the back page of this booklet.

Once set up, all future functions can be organised and set via the app.

## Getting started

### Initial Status

Pressing the unlock icon or scanning an RFID card will unlock the door.



### Indicators



Operate successfully - buzzer long beeps  
- green LED stays for 2 seconds



Operate unsuccessfully - buzzer beeps 2 times  
- red LED flashes 2 times



Bluetooth pair mode - Green LED keeps fast blinking until pair done or exit pair mode

### Notes

- SET button and DEL button are the 2 holes found on the inside handle above the turn knob. DEL is at left, SET is at right side.
- SET button is for setting. DEL button is for deletion or default.
- Each operation should be done within 5 seconds, or it will exit the setting.
- Reset lock - press the DEL button for 3 seconds, then press unlock icon 6 times

## Programming to Right Hand Opening Doors



### Adjust Direction



The Grange is suitable for left hand or right hand opening doors. As a default, it is set as a left hand. If you have a right hand opening door, please adjust the direction of the door to correct the open and locked icons.

- a. press the set button
- b. Press 9
- c. Press 16
- d. Motor will change direction to fit with the door direction

Repeating these steps will return the door to the original direction.

### Bluetooth Pair Mode

Pair your smartphone directly with The Grange to enable all of the functions to be controlled from the app. Follow these steps to pair your phone:



- a. Press the "SET" button for 3 seconds
- b. Press "6"
- c. The green light will flash continually
- d. Input the pairing code. The default is 666000
- e. Once the phone is paired, the green light will stop flashing

Once paired, the pair code can be changed via the smartphone app.

Use the following steps to delete the Bluetooth pairing. Required when the maximum of 10 devices have been paired.



- a. Press the "DEL" button for 3 seconds
- b. Press "6"
- c. All paired Bluetooth connections are deleted

To reset the pair code to the default, press the "DEL" button for 3 seconds, press 9 then press 16.


This is used if you forget your passcode and will reset it to the default (666000).

## New User

### Add a new user with an access code:




#### Create NEW User



- Press the "SET" button for 3 seconds
- Press "1"
- Input a 6-12 digit number of your choice (remember this number)
- Press the lock icon

The new access code has been added

### Add a new user with an RFID card:



- Press the "SET" button for 3 seconds
- Press "2"
- Swipe the card

The new RFID card has been added

## One Time Password

This allows a user to unlock the door once. After the code is used, it cannot be reused. This may be useful if you are expecting visitors or a delivery. The handle will take a maximum of 10 codes at any one time.

### To add One Time Passwords:



#### Add OTP



- Press the "SET" button for 3 seconds
- Press "3"
- Input an access code of your choice of 6-12 digits
- Press the lock icon

### Delete all user codes:



#### Delete User



- Press the "DEL" button for 3 seconds
  - Press "1"
- All user codes are deleted

### Delete all RFID cards



- Press the "DEL" button for 3 seconds
  - Press "2"
- All user RFID cards are deleted

### To delete all One Time Passwords:



#### Delete OTP



- Press the "DEL" button for 3 seconds
  - Press "3"
- All one time passwords are now removed

You can find both one time and **timed passwords** via the app, you can enter a maximum 10 of each.

Timed passwords are very useful in the following scenarios:

B&B accommodation allowing guests access from 1pm-Friday to 10am Sunday

Allowing your cleaner, trade person or visitors access on a certain day or time frame etc.

### Auto Lock Timer

Use the Auto Lock Timer to lock the door after a specified amount of time.



- Press the "SET" button for 3 seconds
- Press "5"
- Input the number of seconds that you want the door to remain unlocked for - up to 99 seconds
- Press the Lock Icon

To cancel the lock function, press 0 and press the lock icon.

### Always open Mode

This stops the door from locking and puts it into passage mode. Useful when gardening, bringing groceries in from the car etc.



After gaining access through the code or smart card, press unlock icon within 3 seconds to activate Always-Open mode. The door will now remain unlocked.

The lock will flash green every 5 seconds to remind you the door is in the unlocked position



To deactivate Always-Open mode, enter password or scan the smart card again.

### Code scrambling technology



When entering your access code, you can add numbers before and/or after the code to disguise it from onlookers. A maximum of 20 numbers can be entered – including the access code.

## Other features



If an incorrect code is entered 5 times, the lock will freeze for 3 minutes. The buzzer will beep 10 times and the red LED will flash 10 times.



When the battery is low, the system will indicate this each time the door is opened by beeping 5 times and the LED will flash 5 times. To change the batteries, undo screw at the bottom of internal handle then pull battery case out.

Requires 8 x AA size.



When the maximum of 100 access codes and/or cards have been programmed, the buzzer will beep twice, and the red LED will stay on for 10 seconds.

## Trouble shooting



If the lock and unlock icons are reversed, see the sections above to reverse the door to left opening or right opening.

## Cleaning and maintenance



Clean only with a clean, damp cloth.

## Warranty

Register your warranty for The Grange at [www.dormakaba.com.au](http://www.dormakaba.com.au)

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. dormakaba Australia Pty Ltd (ABN 14 067 969 466) trading as dormakaba of 12-13 Dansu Ct, Hallam, Victoria 3803 (dormakaba) provides the following warranty in relation to its "The Grange" products (Products).

The benefits of this warranty are in addition to any rights and remedies imposed by Australian State and Federal legislation that cannot be excluded. Nothing in this warranty is to be interpreted as excluding, restricting or modifying any State or Federal legislation applicable to the supply of goods and services which cannot be excluded, restricted or modified.

## **WARRANTY**

dormakaba warrants that, subject to the conditions, exclusions and limitations below, the Products will be free from defects for a period of 1 year.

1. If a defect covered by warranty appears before the end of the Warranty Period, then dormakaba will, in its sole discretion, either:
  - (a) replace or repair the Product or the defective part of the Product free of charge; or
  - (b) refund the price of the Product; or
2. dormakaba reserves the right to replace defective parts of the Product with parts and components of similar quality, grade and composition where an identical part or component is not available.
3. Products presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the Products.

## **WARRANTY CLAIMS**

4. Any claim for warranty must be made, by contacting dormakaba at the address listed above, at the earliest stage that the defect becomes obvious to enable prompt action and to avoid further damage and must be made no later than 1 month from the defect/date of repair becoming obvious.
5. Any warranty claim must be accompanied by appropriate documentation which stipulates the date of the installation, the invoice number, the purchaser name and address, and the alleged defect.
6. The purchaser must make the Product or workmanship available to dormakaba for inspection and testing. If dormakaba finds no fault in the Product or its workmanship, then the purchaser must pay dormakaba's usual costs of service work, inspection and testing.
7. Warranty work will be conducted by dormakaba during normal working hours (8.00am to 5.00pm Monday to Friday).

## **EXCLUSIONS**

8. The purchaser acknowledges that the Products are not indestructible, and that some care in installation and maintenance is necessary. No liability is accepted for, and this warranty does not apply to:
  - (a) any damage caused by misuse or failure to adhere to the manufacturer's selection and installation specifications, instructions or recommendations;
  - (b) fair wear and tear;
  - (c) defects arising due to the installation of the Products where the Products were not installed by dormakaba or its agents;
  - (d) any damage or defects caused to the structures the Products are installed in, where the Products were not installed by dormakaba or its agents;
  - (e) damage caused by circumstances beyond dormakaba's control;
  - (f) any damage or defects within acceptable industry variances;
  - (g) Products that have been used other than for the purpose for which they were designed;
  - (h) damage caused by exposure to abnormal conditions, including but not limited to environment, temperature, water, fire, humidity, pressure, stress or similar;
  - (i) defects that arise due to abuse, misuse or neglect;
  - (j) Products that have been modified, built on or repaired;
  - (k) Products that have not been maintained as recommended by dormakaba;
  - (l) maintenance items (which are the responsibility of the purchaser);
  - (m) Products installed, maintained or operated other than in accordance with dormakaba's instructions; and
  - (n) overhaul, replacement or repair works undertaken prior to approval from dormakaba of any warranty claim.

## **LIMITATIONS**

9. dormakaba makes no express warranties or representations other than set out in this warranty.
10. dormakaba reserves the right to alter product specifications and introduce improvements at any time.



**IOS App Store**



**Google Play**

dormakaba Australia  
Head Office  
12-13 Dansu Court  
Hallam VIC 3803  
T: 1800 675 411  
info.au@dormakaba.com  
www.dormakaba.com.au

dormakaba New Zealand  
Head Office  
Building P, 61-69 Patiki Road  
Avondale, Auckland 1026  
T: 0800 436 762  
info.nz@dormakaba.com  
www.dormakaba.co.nz