
















RLT254CSEON/RLT254CSEON13/RLT254SSEON/RBC254SSEON/RPP254FEJSO

⚠ WARNING: This procedure sheet is not a substitute for reading the operator's manual. To reduce the risk of injury, the user must read and understand the operator's manual before using the product.


TO START A COLD ENGINE:

- ①  50:1 Ratio = Mix 20 mL of synthetic 2-stroke oil per litre of petrol. Ensure the fuel is fresh and is correctly mixed before pouring into the fuel tank.
- ②  Slowly press the primer bulb 10 times or until the fuel appears.
- ③  Set the choke lever to "full" choke position.
- ④  Hold down the throttle lock, and then squeeze the throttle trigger.
- Using manual operation:
Pull the starter grip and rope (4x maximum) until the engine attempts to start.
- or
- ⑤  Using ONE+ EASYSTART Module:
Set the ONE+ EASYSTART Module to , insert into the starter housing, and then press the ONE+ EASYSTART's power button until the engine attempts to start (**4 seconds maximum**).
- ⑥  Set the choke lever to "half" choke position.
- Using manual operation:
Pull the starter grip and rope (6x maximum) until the engine starts.
- or
- ⑦  Using ONE+ EASYSTART Module:
Set the ONE+ EASYSTART Module to , insert into the starter housing, and then press the ONE+ EASYSTART's power button until the engine starts (**4 seconds maximum**).
NOTE: If the engine does not start, repeat the procedure from step 3 until the engine starts.
- ⑧  Allow the engine to warm for 10 seconds. Set the choke lever to "run" position.

TO START A WARM ENGINE:

- ①  Slowly press the primer bulb 10 times or until the fuel appears.
- ②  Set the choke lever to "run" position.
- ③  Hold down the throttle lock and then squeeze the throttle trigger.
- Pull the starter grip and rope until the engine runs. Do not pull the starter grip more than six times.
- or
- ④  Using ONE+ EASYSTART Module:
Set the ONE+ EASYSTART Module to , insert into the starter housing, and then press the ONE+ EASYSTART's power button (**4 seconds maximum**).

TO STOP THE PRODUCT:

- ⑨  Push the on/off switch to the "off" position.

