


SHAPES RANGE

RAISED GARDEN BED

'10 IN 1' SHAPES

KEY

NUMBER OF CORNER PIECES REQUIRED:




NB: Joining of corner pieces creates the required angle for the shape of bed being assembled.

NUMBER OF SHEETS REQUIRED:


5 6 7 8

LAYOUT IDEAS




PLEASE NOTE

The slimline bed requires a brace 3rd hole from the bottom. If you wish to assemble into this configuration please use the supplied materials and set up as below.



[W] www.birdiesgardenproducts.com.au
[T] 1300 424 734



ADDING PANELS THAT ARE NOT SHOWN ON THE CONFIGURATION DIAGRAMS WILL RESULT IN FAILURE

ASSEMBLY



Before assembly and whilst unpacking, please be aware that there are sharp corners and edges that could cause injury and it is advisable to wear protective gloves when handling these items, sensible shoes are also recommended. Until such time as the SAFETY EDGE is fitted all necessary precautions need to be undertaken to avoid injury.

IMPORTANT!! We recommend placing the bottom edge of the bed on a 25-50mm layer of 10-20mm gravel, this allows excellent drainage and protects the bottom edge of the bed. Also placing the bed on level ground is advised.

STEP 1


Remove protective plastic covering (on all coloured beds).

STEP 2

Please select the shape you wish to assemble using the configuration diagrams.

STEP 3

Please follow assembly diagram placing all wing nuts in loosely initially and then tighten. A wing nut tool is supplied. Failure to tighten each wing nut and bolt to its maximum may cause failure. A screwdriver or cordless drill may assist with this process.



ENSURE THAT YOU ATTACH THE CORNERS ON THE OUTSIDE OF THE STRAIGHT SHEETS

STEP 4

Simply push the edging onto the rolled steel edge and trim excess. The safety edging is designed to lock onto the rolled steel edge making it more permanent.

IMPORTANT!!

If filling the bed with a bobcat or backhoe fill the initial 1/3 of bed slowly. Also when filling your veggie bed do not climb in as this puts unnecessary pressure onto the bed.