

## INSTALLATION INSTRUCTIONS

### SPACE BLANKET®

**These instructions should be read in conjunction with local standards AS 3999 and all applicable local, state and federal building regulations. Before you start installing, please make sure you are familiar with our Health and Safety Information contained in this document. Ensure that you use tools and equipment that are suitable for the intended application. This will include suitable safety equipment.**

#### **Do not start work until the site is safe!**

Assess the roof condition and structure together with the method of installation you are to use based on the appropriate requirements established in the building code, site assessment and or plans provided. Installation must be completed to the requirements of relevant standard: AS 3999:2015.

#### **Tools required:**

- Sharp knife for trimming insulation
- Ladder
- Suitable clothing (see our Health and Safety Information)
- Tape measure

#### **STEP 1**

- To calculate the number of packs needed, determine the area (m<sup>2</sup>) to be insulated by multiplying the length by the width. The number of m<sup>2</sup> of insulation material is clearly marked on each pack. Divide the total area to be insulated by the m<sup>2</sup> in a pack to determine the number of packs required (don't forget to round up to the nearest whole pack). Allowances should be made for areas that are unable to be insulated.
- Where required, use a sharp knife to cut the insulation to fit. It is important when you cut the insulation that you avoid coming into contact with any electrical services.

#### **STEP 2**

- Don't take the insulation out of the packaging until you're in a position and ready to install.

#### **STEP 3**

- Start installing the insulation at the far ends of the roof and work your way back towards the ladder. Position the start of the roll at the ridge batten with the foil facing down into the roof cavity below and roll towards the fascia/gutter.
- Allow the blanket to sag in between the battens to recover to its nominal thickness. The insulation should always maintain continuous contact with the roof sheets once laid.
- Roll out the next blanket side by side to the first ensuring it overlaps on top of the foil lap from the previous roll. Ensure there are no gaps.
- The blanket must be trimmed level with the fascia/gutter leaving the foil to continue into the gutter to allow any condensation to runoff into the fascia/gutter.
- Do NOT allow the blanket to fall into the fascia/gutter as it can draw water back into roof space.
- Repeat previous steps until the entire roof is complete.

#### **STEP 4**

- Complete the final check of the roof ensuring all areas have been insulated and that you have an even consistent layer of insulation.
- Finish your project by removing all packaging from the roof and disposing of all rubbish and excess insulation responsibly.

#### **STEP 5**

- Once the roof area is completely covered with no gaps you are now ready to install the roof sheets in accordance with the roof manufacturer's instructions.

We recommend that once completed another person checks the work to ensure it has been installed according to required standards.

## HEALTH AND SAFETY INFORMATION

### SAFETY WARNINGS AND HAZARDS

- You must turn the mains power 'Off' before entering the work space, and, if in any doubt about how to turn the power 'Off', you must consult a licensed electrician.
- Working in areas that contain live electrical wiring is extremely hazardous. Take extreme care to avoid touching any live overhead electrical lines, supply cables or any other live cables in the workspace.
- Defective electrical cables, exposed terminals and conductors of electrical equipment such as light fittings and fans can cause burns and electric shocks please exercise caution when working near such hazards – check with an electrician if you are unsure if the cabling is safe.
- Working in hot and poorly ventilated areas when installing insulation can be dangerous.
- Working at heights, when installing insulation can be dangerous.

### BEFORE INSTALLATION

- You must turn the mains power 'Off' and, if in any doubt about how to turn the power 'Off', consult a licensed electrician.
- Do not enter the workspace for the purposes of the pre-work inspection or the installation until you are satisfied that the power has been isolated. Even after isolating the power via the switchboard there may still be an electrical mains cable in either the ceiling or underfloor space that is live.
- Complete a pre-work assessment before installation to identify safety hazards which may include but are not limited to the following:
  - access to the roof area,
  - working at heights,
  - electrical safety hazards,
  - adequate ventilation of the work area and
  - nails and sharp objects on the ground
- Before commencing work you must have systems in place to reduce risks identified in the pre-work assessment such as but which are not limited to:
  - systems to prevent falling when working at heights.
  - ventilate the working area if possible.
  - cover exposed skin. When working in an unventilated area, wear a disposable face mask.
  - rinse hands in cold water before washing.
  - wear goggles when working overhead.
  - clean using vacuum equipment.

### DURING INSTALLATION

- Work with another person and maintain contact throughout both the assessment and installation process.
- Only open bags as required.
- Wear appropriate clothing for the job such as long sleeved top, flat rubber sole shoes, gloves conforming to Australian Standard AS 2161 and ventilated non-fogging dust resistant goggles conforming to AS/NZS 1336, and a P2 dust mask.
- Avoid eye contact with dust or fibres to minimise eye or skin contact and inhalation during handling.
- Avoid installing insulation in hot weather and at the hottest part of the day.
- Under no circumstances must fixing devices in ceiling spaces or under floors, or in proximity to electrical wiring, be of metal or other conductive material.

### Proven Performance

- Preferred by professional installers concerned with quality, appearance and productivity.
- Excellent acoustical properties reduce sound transmission in the home when properly installed.

## HEALTH AND SAFETY INFORMATION

### ELECTRICAL SAFETY CONSIDERATIONS BEFORE ISOLATING POWER

- Locate and review the incoming power supply, main switchboard and meter box.
- Ensure you understand if there is a main isolator and how power can be safely isolated.
- Ensure you understand the direction of the 'On' and 'Off' position of the main switch (NOTE: the 'Off' position is not always as it seems - check with an electrician if you are unsure).
- Before installation, switch 'Off' the electricity supply at the main switchboard (check with an electrician if you are unsure if power can be turned 'Off' at the switchboard).
- Be aware that even after isolating the power via the switchboard there may still be an electrical mains cable in either the ceiling or underfloor space that is live. Take extreme care to avoid touching any live overhead electrical lines, supply cables or any other live cables in the workspace.

### PROCEDURE FOR ISOLATION - CERAMIC FUSES (IF IN DOUBT YOU MUST CONSULT A LICENSED ELECTRICIAN)

- Ceramic fuses are typically found in older style homes.
- Identify if any fuse is deactivated.
- Check if there are any fuses currently in the 'Off' position, take note of them.
- Place a strip of electrical tape over main switch isolator after it is turned 'Off'.
- Apply additional strips of electrical tape over the deactivated fuse and any individual isolator in the 'Off' position as a reminder to leaving it in the 'Off' position once the re-activation procedure has been completed.
- If you find a fuse plug out of its socket, whilst the main isolator is in the 'Off' position, place electrical tape over its respective switch and one over the fuse socket opening.
- DO NOT touch the internal metal fittings.
- Place a written note on the main isolator switch or meter box enclosure to advise the power is 'Off' and WORK IN PROGRESS is occurring.
- Check to ensure the lights and appliances, within the home, previously left on are no longer operating to confirm the mains power is now isolated.
- The original person who placed the isolation tag is the only one who can re-activate the power. Advise occupants of this requirement.

### PROCEDURE FOR ISOLATION CIRCUIT BOARD (IF IN DOUBT YOU MUST CONSULT A LICENSED ELECTRICIAN)

- Circuit boards are typically found in modern homes.
- Check if there are any switches currently in the 'Off' position, take note of them.
- Place a strip of electrical tape over main switch isolator after it is turned 'Off'.
- Apply additional strips of electrical tape over any deactivated fuses or individual switches in the 'Off' position after isolating the mains power as a reminder to leave it in the 'Off' position once the re-activation procedure has been completed.
- Turn 'Off' all individual switches on the circuit board.
- Place a written note on the switches or meter box enclosure to advise the power is 'Off' and WORK IN PROGRESS is occurring.
- Check to ensure the lights and appliances within the home previously left on are no longer operating to confirm the mains power is now isolated.
- The originator that placed the isolation tag is the only one who can re-activate the power. Advise occupants of the requirement.

### REACTIVATING THE POWER

- After the completion of the installation, switch the mains power to the 'On' position (for ceramic fuse board), but for a circuit board, switch the main power 'On' and then each individual power isolator on one at a time. The taped switches in the 'Off' position should stay switched 'Off'.
- **WARNING:** If you cannot reconnect power please ensure you seek assistance from a qualified electrician.

### SUITABLE CLOTHING

- When handling any insulation material, especially in enclosed poorly ventilated areas and/or overhead, the use of suitable eye protection conforming to AS1336 will greatly reduce contact with dust or fibres.
- Wear suitable loose fitting clothes, including long sleeved shirts, long pants, cap and gloves.
- A suitable dust mask is recommended when working in confined, poorly ventilated and dusty areas.
- Wash work clothes separately and rinse the washing machine after use.