

 **Crommelin**®

Waterproofing



Waterproofing
Membranes

Product Guide

Why Waterproof?

- Waterproofing keeps water where you want it and not where you don't
- Protect your home from structural and cosmetic water damage
- Prevent dangerous and unsightly mould and mildew
- Promote long term building comfort and performance
- Save money by avoiding difficult and costly repairs

What to consider when choosing a waterproofing membrane

- Where are you applying?
- What key performance features do you need?
- Is your drainage design adequate for your project?
- Does your project require positive or negative side waterproofing?




Liquid applied membrane advantages

Liquid applied waterproofing membranes:

- Provide a highly waterproof protective barrier
- Allow for seamless application, eliminating points of moisture ingress
- Are permanently flexible to accommodate structural movement
- Deliver a high strength bond to substrate
- Are highly durable with good chemical and abrasion resistance


Typical Sheet Membrane



Sheet
membrane

Point of
moisture ingress

Liquid Applied Membrane



Liquid membrane

Reinforcing fabric
(for joints and detailing)

Liquid membrane

When to waterproof

- Waterproofing should be included as part of any construction project, rather than as a secondary thought
- Waterproofing should only be applied to dry and sound substrates
- Only waterproof when the correct membrane has been chosen for the project

When not to waterproof

- When the substrate is damp (unless suitable product is chosen)
- When the substrate is dusty or friable
- During times of temperature extremes – hot or cold
- If rain or high humidity is expected during cure phase


1800 655 711 – 7 day technical advice line

Waterproofing

Positive or negative waterproofing


Positive side waterproofing

- When movement of moisture is from the front of the waterproofing coating, effectively pushing the membrane onto the substrate
- Both positive and negative waterproofing membranes may be used in this situation
- Correct film thickness of coating must be applied to ensure waterproofing performance



Negative side waterproofing

- When movement of moisture comes through the substrate, behind the waterproofing coating, effectively trying to push the membrane off of the substrate
- Only use waterproofing coatings specifically engineered for negative hydrostatic pressure situations
- Correct film thickness of coating must be applied to ensure waterproofing performance



Where am I waterproofing?



Below ground and non-exposed waterproofing

- Membrane must be applied to the positive side of the structure
- Substrate must be completely dry and correct film thickness is vital
- Membrane must be protected from damage during back filling
- Suitable applications include retaining walls, timber posts, planter boxes and pots.
- Suitable substrates include concrete, brick, timber, metal and most other common construction materials



Wet area and under tile waterproofing

- Membrane must be applied to the positive side of the structure
- Substrate must be completely dry and correct film thickness is vital
- Tiles may be directly adhered to membrane
- Suitable applications include showers, bathrooms, kitchens, wet areas, balconies and swimming pools. (in conjunction with epoxy grout)
- Suitable substrates include concrete, brick, timber, ply, cement sheeting and most other common construction materials



Exposed area waterproofing

- Membrane must be applied to the positive side of the structure
- Only highly durable membranes with good UV resistance should be used
- Substrate must be completely dry and correct film thickness is vital
- Suitable applications include roof decks, gutters and gardens, balconies and terraces prior to over coating
- Suitable substrates include concrete, brick, timber, metal, cement sheeting and most other common construction materials



Damp substrates and negative side waterproofing

- Membrane may be applied to either positive or negative side of the structure
- Substrate may be damp, but without standing water
- Correct film thickness is vital
- Suitable applications include water retaining structures, basements, retaining walls, high traffic areas and damp substrates
- Suitable substrates include concrete, brick, timber, cement sheeting and most other common construction materials

Surface preparation

Surfaces must be clean

- Remove all surface contaminants including dirt, dust, grease, oil, mould, cement laitance and curing compounds
- If surface has been ground, remove dust by vacuum and pressure wash or wet vac
- If surface is not clean, membrane adhesion will be compromised
- Poor adhesion will lead to delamination of the membrane
- If surface contaminants or residues cannot be removed, the use of an epoxy primer such as Crommelin Dampstop may assist with membrane adhesion

Surfaces must be sound

- Dusty or friable surfaces must be primed prior to membrane application
- Surface priming will ensure maximum membrane adhesion
- Method of priming is dependent upon choice of membrane
- Surface imperfections should be removed or made good with suitable repair mortar
- All surface protrusions must be removed to provide a smooth surface for membrane application
- Surface imperfections are a common cause of membrane failure and water ingress

Surfaces must be dry

- A moisture test must always be done to ensure that substrate is dry enough to waterproof
- It is recommended to use electronic moisture meters
- If the substrate is damp, without standing water, a suitable damp substrate waterproofing membrane must be used
- Waterproofing damp substrates may compromise adhesive strength of the membrane
- Bubbles and blisters may appear in the membrane if excessive moisture is present in the substrate

Drainage

- Adequate falls and drainage must form part of any building design, to ensure maximum performance of waterproofing membranes
- Inadequate drainage may lead to membrane failure and costly water damage

Previously waterproofed surfaces

- Ensure that the existing coating is compatible with the new membrane
- Ensure that the existing coating is well adhered to substrate
- Areas of damage or leaking should be repaired
- If in doubt, remove existing membrane before re-application

Membrane application

- Correct waterproofing membrane should be chosen for project, service and substrate
- Reinforcement of construction joints and corners is recommended with Crommelin Reinforcing Bandage
- Apply membrane with Crommelin Membrane Applicator Brush or Roller to ensure optimum membrane delivery
- Ensure that environmental conditions, including temperature and humidity, are suitable for membrane application
- Always apply membrane at the correct coverage rate to ensure correct film thickness
- Apply second coat at 90° to the first to ensure full coverage
- Ensure membrane does not become too thick at corners
- Provide adequate ventilation and air flow to assist cure
- Do not expose to water until full cure has been achieved
- Protect membrane from damage during back filling or over-coating. Do not overcoat until full cure has been achieved



1800 655 711 – 7 day technical advice line

Waterproofer Selector Guide	Product	
	Application	Postvie/Negative Side Application
Product		
Blackseal	Below ground & Non-Exposed	+
Water Based Bitumen Paint		+
Shower Waterproofing Membrane	Wet Area & Under Tile	+
Liquid Reinforcing Fabric		+
Shower Sealer		+
Exterior Grade Waterproofing	Exposed	+
Pond Sealer - Colours		+
Pond Sealer - Clear		+
Dampstop	Damp Substrates & Negative Side	+/-
Trowel On Waterproofing		+/-

		Substrates													
Colour	Potable Water Safe	Brick	Cement Sheeting	Chip & Ply Board	Concrete	Concrete Block	Existing Membranes	Fibre Glass	Grout	Metal	Plaster Boards	Render	Screeds & Levellers	Scyon Board	Timber
Black	●	●			●	●						●			
Black	●	●			●	●						●			
Green		●	●	●	●	●	●	●	●	●	●	●	●	●	●
Green		●	●	●	●	●	●	●	●	●	●	●	●	●	●
Clear									●						
Grey	●	●	●	●	●	●	●	●		●	●	●	●	●	●
Black/SST/Blue		●	●	●	●	●	●	●			●	●	●	●	●
Clear		●	●		●	●	●		●			●	●	●	
Grey		●	●		●	●	●	●		●	●	●	●	●	●
Grey	●	●	●		●	●	●				●	●	●	●	●

Product Guide



Below Ground & Non-Exposed

Blackseal

- Non-exposed waterproofing membrane
- Long term durability and permanent flexibility
- Suitable for retaining walls, timber posts etc
- Fast drying

Coverage: 1.5m² per litre, 2 coats

Recoat/Cure time: 2-4 Hours / 7 Days

Packaging: 4L, 20L

Water Based Bitumen Paint

- Non-exposed waterproofing membrane
- Excellent substrate adhesion
- Suitable for planter boxes, pots and water tanks
- Potable water safe

Coverage: 1.5m² per litre, 2 coats

Recoat/Cure time: 2-4 Hours / 7 Days

Packaging: 1L, 4L, 15L



Tips

- *Ensure that all surface imperfections are made good prior to membrane application*
- *Membrane must be fully cured before back filling*
- *Protect membrane from puncture during back filling with corflute or other protection board*

Wet Area & Under Tile

Shower Waterproofing Membrane

- Class III membrane for wet area and under tile waterproofing
- High elongation and permanent flexibility
- Excellent primer-less adhesion and fast drying
- Keyed finish, suitable for use with all cement based tile adhesives

Coverage: 2m² per litre, 2 coats

Recoat/Cure time: 2-4 Hours / 7 Days

Packaging: 1L, 4L, 15L

Shower Waterproofing Membrane Kit

- Includes everything you need to waterproof your wet area
- 4L kit suitable for a single shower recess
- 6L kit suitable for a double shower recess
- Detailed application instructions included

Coverage: 2m² per litre, 2 coats

Recoat/Cure time: 2-4 Hours / 7 Days

Packaging: 4L, 6L

Liquid Reinforcing Fabric

- Fibre reinforced waterproofing membrane for wet area and non-exposed applications
- Replaces traditional reinforcing bandages
- Strengthens membrane against puncture and tears at corners and construction joints
- Fast and easy to apply

Coverage: 2m² per litre, 2 coats

Recoat/Cure time: 2-4 Hours / 7 Days

Packaging: 1L, 4L

Shower Sealer

- Highly penetrative waterproofing solution to fix leaking showers
- Permanently waterproofs old and porous tile grout
- Invisible protection
- Interior and exterior application

Coverage: 500ml will treat two average showers (approx. 200-300LM of 5mm grout)

Recoat/Cure time: Single coat / upon application

Packaging: 500ml





Exposed

Exterior Grade Waterproofing

- UV resistant waterproofing membrane
- High elongation and flexibility
- Suitable for over coating with most acrylic paints and renders
- Potable water safe

Coverage: 1.5m² per litre, 2 coats

Recoat/Cure time: 2-4 Hours / 7 Days

Packaging: 1L, 4L, 15L

Pond Sealer - Colours

- Textured decorative waterproofing membrane
- Highly flexible and may be tiled over
- Fish and plant safe formulation
- Available in black, sandstone and blue

Coverage: 1.5m² per litre, 2 coats

Recoat/Cure time: 2-4 Hours / 7 Days

Packaging: 1L, 4L, 15L (Black only)

Pond Sealer - Clear

- Clear waterproofing treatment
- Non-flexible
- Fish and plant safe formulation
- Use in conjunction with Crommelin Dampstop on in-ground ponds

Coverage: 6-10m² per litre, 3 coats

Recoat/Cure time: 4 Hours / 7 Days

Packaging: 1L



Tips

- Always apply two coats of membrane at the correct coverage rate
- Apply second coat of membrane at 90° to the first to ensure that no areas have been missed

Damp Substrates & Negative Side

Dampstop

- Two part water borne epoxy waterproof barrier
- Suitable for positive and negative side and damp surface waterproofing
- Over-coatable with Crommelin waterproofing membranes and most acrylic paints
- Also suitable as a tough coating for high traffic floors

Coverage: 5-7 m² per litre, 2 coats

Recoat/Cure time: 4-6 Hours / 7 Days

Packaging: 1L

Trowel On Waterproofing

- Two part cementitious waterproofing membrane
- Remains permanently flexible
- Suitable for negative and damp substrate waterproofing
- May be over-coated with acrylic paints and renders

Coverage: 0.75-1m² per kg, 2 coats

Recoat/Cure time: 16-72 Hours / 14 Days

Packaging: 14kg kit



Tips

- *Always ensure that two component membranes are mixed in the correct ratio and for the recommended amount of time*
- *It is recommended to always mix an entire kit*
- *When using cement based membranes, such as Crommelin Trowel On Waterproofing, the substrate must be wet upon application (but without standing water) to ensure optimum curing conditions*



Accessories

Applicator Brush

- Quality tapered synthetic filament for easy film build
- Optimum coating pick up and release
- Will not clog, even when used with highly viscous coatings
- Suitable for use with Crommelin waterproofing membranes and clear sealers

Packaging: 100mm brush

Applicator Roller

- Quality polyester fabric for easy film build
- Optimum coating pick up and release
- Will not clog, even when used with highly viscous coatings
- Suitable for use with Crommelin waterproofing membranes and clear sealers

Packaging: 230mm roller

Applicator Wheel

- Attached directly to Crommelin Shower Sealer bottles
- Clean and accurate sealer application
- Includes two wheel widths to suit wall and floor grout lines
- Fast and easy to use

Packaging: Includes 3mm and 5.5mm rollers

Reinforcing Fabric

- Non-woven, rot proof 100% polyester
- Superior elongation compared to fibre glass mat
- Increases membrane strength and puncture resistance
- Easy wet out and installation

Packaging: 100mm x 10m roll, 100mm x 50m roll and 200mm x 50m roll

Reinforcing Fabric with Bond-breaker

- Self adhesive polyester fabric tape
- Acts as a bond breaker over movement critical joints and corners
- Easy to shape and apply
- For use with Crommelin Shower Waterproofing Membrane to meet AS3740

Packaging: 100mm x 6m roll



Accessories

Polyurethane Sealant & Bond Breaker

- Permanently flexible with $\pm 25\%$ movement capability
- Excellent substrate adhesion
- High recovery rate
- For use as a bond breaker or general purpose construction sealant

Packaging: Grey 600ml

Silicone WP Plus

- Neutral cure, anti-fungal formulation
- Sanitary grade for interior and exterior use
- Excellent adhesion
- Permanently flexible with $\pm 25\%$ movement capability

Packaging: White / Grey / Translucent 300g cartridges

High Performance Bonding Agent

- Primer for cementitious surfaces prior to waterproofing
- Promotes adhesion of waterproofing membranes to substrate
- Reduces substrate porosity
- Also suitable for use to improve performance of cement mortars and renders

Coverage: 6-10m² per litre

Recoat/Cure time: Apply top coat whilst tacky

Packaging: 1L



Tips

- The use of a bond breaker is recommended in all wall to floor, wall to wall and construction joints to prevent membrane damage caused by structural movement
- Reinforcing fabric also provided added strength to membranes, preventing puncture from sharp tile edges during installation

Waterproofing

How to permanently prevent leaking showers

Crommelin Shower Waterproofing Kit contains all the materials required to permanently waterproof a shower recess. Crommelin Shower Waterproofing Kits include the premium Crommelin Shower Waterproofing Membrane, engineered for use under tiles in all wet area applications.

Crommelin Shower Waterproofing Kits contain waterproofing membrane, reinforcing fabric with bond breaker, an application brush and all the instructions required to a successful waterproofing job.



Suitable Substrates

- Concrete
- Brick
- Cement Sheeting
- Render
- Timber Panel



What Product To Choose?

- Crommelin Shower Waterproofing Kit 4L
- Crommelin Shower Waterproofing Kit 6L



Surface Preparation

- All surfaces must be completely dry, clean and sound
- Surfaces may be primed with a 50:50 solution of Crommelin Shower Waterproofing Membrane and clean water
- For maximum membrane adhesion, prime surfaces with Crommelin High Performance Bonding Agent



Application Tools

- Crommelin Shower Waterproofing Kits contain all the necessary tools required



Coverage

- 4L kit will waterproof a 2 wall shower recess
- 6L kit will waterproof a 3 wall shower recess



Recoat/ Cure Time (at 25°C)

- 2 coats of Crommelin Shower Waterproofing Membrane are required
- Apply second coat at 90 degrees to the first
- Allow 2- 4 hours drying time between coats
- May be tiled over after 24 hours



Tips

- *Ensure adequate air flow during the membrane cure phase. The use of fans to circulate air is recommended*
- *Pre-cut reinforcing fabric prior to installing in corners and around drainage outlets*
- *Do not allow membrane application to become too thick in corners, leading to reduced flexibility*
- *Always ensure the correct use of bond breaking tape*

How to fix damaged and leaky gutters

Crommelin Exterior Grade Waterproofing is a high performance waterproofing membrane engineered for use in areas subject to permanent water immersion.

Available in grey, Crommelin Exterior Grade Waterproofing has excellent adhesive strength and is extremely strong especially when applied in conjunction with reinforcing fabric.



Suitable Substrates

- Metal
- Concrete
- Plywood
- Cement sheet



What Product To Choose?

- Crommelin Exterior Grade Waterproofing



Surface Preparation

- All surfaces must be completely dry, clean and sound
- If surface is rusty, treat area with suitable treatment and ensure that all loose rust material has been removed



Application Tools

- Crommelin Applicator Brush or Crommelin Applicator Roller



Coverage

- Coverage rates will depend upon surface porosity
- 1L of product will cover approximately 0.75m² finished



Recoat/ Cure Time (at 25°C)

- A minimum of 2 coats are required
- Apply second coat at 90 degrees to the first
- A third coat may be required to reach required membrane thickness
- Allow 2 – 4 hours between coats
- Allow 24 hours before exposing membrane to moisture



Tips

- Any areas of gutter damage, pin holing or rust should be reinforced using Crommelin Reinforcing Bandage, installed as part of the first coat
- Ensure that membrane remains free of gutter debris and water flow across the areas is not impeded
- May be overcoated with most acrylic paints and renders

How to fix leaking showers

Crommelin Shower Sealer is a premium performance waterproofing solution, engineered to permanently seal leaking grout, effectively forming a physical mineralised barrier inside your wall.

Easily applied and fast acting, Crommelin Shower Sealer has the ability to bridge minor grout cracking and stays active in the substrate.

Used in conjunction with Crommelin Silicone WP Plus silicone sealant, Crommelin Shower Sealer minimises shower down time and repair costs.



Suitable Substrates

- Grout
- Concrete
- Mortar
- Most other cementitious materials



What Product To Choose?

- Crommelin Shower Sealer
- Crommelin Silicone WP Plus



Surface Preparation

- All surfaces must be completely dry, clean and sound
- The longer you can leave the shower to dry out, the greater the penetration of Shower Sealer
- Any loose grout must be removed and repaired as per manufacturer's instructions
- Ensure that any areas of mould growth are effectively treated with appropriate cleaning chemicals



Application Tools

- Crommelin Applicator Wheel
- Small brush



Coverage

- 500ML is enough material to treat 2 average sized shower cubicles



Recoat/ Cure Time (at 25°C)

- Crommelin Shower Sealer is a 1 coat system
- Ensure that application directions are closely followed, particularly the amount of time between application and introduction of water
- Sealer must be watered in between 30 minutes and 4 hours after application



Tips

- *Do not let Shower Sealer dry on the surface of tiles. Remove excess material with a damp cloth*
- *Ensure that all wall to floor and wall to wall joints are sealed with flexible sanitary grade silicone sealant and not rigid grout*
- *Double thickness mask each side of silicone joint with masking tape, to ensure that a thick edge to silicone is maintained once smoothed*

Waterproofing

How to waterproof fish ponds

Crommelin Pond Sealer is engineered for use as a waterproofing membrane in fish ponds and water features, providing a tough, flexible and waterproof membrane with a decorative textured finish.

Available in Black, Blue and Sandstone, Crommelin Pond Sealer will transform any plain pond into a decorative garden feature.

Crommelin Pond Sealer is safe and will not harm aquatic animals or plants.



Suitable Substrates

- Concrete
- Brick and Render
- Cement sheet



What Product To Choose?

- Crommelin Pond Sealer Colours - Black, Blue and Sandstone
- Crommelin Pond Sealer Clear - for above ground water features only



Surface Preparation

- All surfaces must be completely dry, clean and sound
- If pond is in-ground, a negative side membrane such as Crommelin Dampstop should be used before the application of Crommelin Pond Sealer Colours
- Reinforcing fabric and bond breakers should be used in all wall to floor, wall to wall and construction joints



Application Tools

- Crommelin Applicator Brush or Crommelin Applicator Roller



Coverage

- Coverage rates will depend upon surface porosity
- Pond Sealer colours – 1L will cover approximately 0.75m²
- Pond Sealer clear – 1L will cover approximately 3-5m²



Recoat/ Cure Time (at 25°C)

- A minimum of 2 coats of Pond Sealer Colours are required
- Apply second coat at 90 degrees to the first
- A third coat may be required to reach required membrane thickness
- Allow 2 – 4 hours between coats
- A minimum of 3 coats of Pond Sealer Clear is required
- Allow 4 hours between coats
- For all Pond Sealer membranes, allow 7 days for full cure before filling your water feature



Tips

- Ensure membrane is protected from moisture or high humidity during the cure phase
- Pond Sealer Clear may turn white if exposed to moisture prior to full cure

How to waterproof retaining walls & planter boxes

Crommelin Water Based Bitumen Paint is a premium, tough and flexible waterproofing membrane engineered for use in non-exposed and below ground applications.

Easy and economical to use, Crommelin Water Based Bitumen Paint is highly effective and safe for the environment.

Crommelin Water Based Bitumen Paint is recommended for use on non-critical retaining walls, planter boxes and pots.



Suitable Substrates

- Concrete
- Brick and masonry
- Render
- Timber and timber panel



What Product To Choose?

- Crommelin Water Based Bitumen Paint



Surface Preparation

- All surfaces must be completely dry, clean and sound
- If surface remains damp, use Crommelin Dampstop as a primer
- Surface defects must be removed or filled with suitable repair mortar
- Suitable bond breaker and reinforcing fabric should be installed in all wall to floor, wall to wall and construction joints



Application Tools

- Crommelin Applicator Brush or Crommelin Applicator Roller



Coverage

- Coverage rates will depend upon surface porosity
- 1L will cover approximately 0.75m² finished



Recoat/ Cure Time (at 25°C)

- 2 coats of Crommelin Water Based Bitumen Paint are required
- Apply second coat at 90 degrees to the first
- Allow 30 minutes drying time between coats
- Allow 7 days for full cure and before back filling



Tips

- Ensure that membrane is protected from puncture during back filling by installing core flute or other protection board
- Crommelin Water Based Bitumen Paint is not suitable for use as an under tile membrane or in UV exposed conditions
- Mix sand with Crommelin Water Based Bitumen Paint to create a waterproof mortar

How to waterproof brick walls & other masonry surface

Crommelin Natural Finish Sealer is a highly penetrative and water repellent sealer engineered to for use as a waterproofing coating for masonry walls exposed to rain and moisture.

Suitable for both interior and exterior use, Crommelin Natural Finish Sealer may be easily applied to most porous surfaces.

Crommelin Natural Finish Sealer's water repellent action delivers long term protection, without changing the appearance of the treated surface.

Suitable Substrates

- Concrete
- Brick and masonry
- Render
- Natural Stone

What Product To Choose?

- Crommelin Natural Finish Sealer

Surface Preparation

- All surfaces must be completely dry, clean and sound
- Surface defects must be removed or filled with suitable repair mortar
- Efflorescence may be removed with Crommelin Efflorescence Remover
- Ensure that any areas of mould growth are effectively treated with appropriate cleaning chemicals

Application Tools

- Crommelin Applicator Brush or Crommelin Applicator Roller
- Garden spray

Coverage

- Coverage rates will depend upon surface porosity
- 1L will cover approximately 3-5m² finished

Recoat/ Cure Time (at 25°C)

- 2 coats of Crommelin Natural Finish Sealer are required for maximum protection
- Allow 30 minutes drying time between coats
- Protect surface for 24 hours from exposure to rain and moisture
- Allow 7 days for full cure

Tips

- Conduct a moisture test before application to ensure maximum penetration of sealer into substrate
- Do not apply a penetrating sealer over a satin or gloss topical sealer. The penetrating sealer will remain on the surface and become sticky

Troubleshooting & maintenance

Blisters and bubbles in membrane

- This is generally caused when moisture is trapped beneath a positive side waterproofing membrane
- Moisture may be from uncured concrete, rain and water leakage, or from under applied membranes with too thin a film build
- To rectify, blisters may be cut out (taking care not to damage underlying surface), surface allowed to fully dry and a repair coat applied

Membrane cracking

- Cracking of a waterproofing membrane may be caused by too thick an application in a single coat. Areas of membrane that are too thick may not perform as required due to compromised movement capability
- Cracking may also be caused by membrane application in hot or windy conditions, leading to surface drying taking place too quickly
- To rectify areas of cracked membrane, it is recommended that the effected area is removed and repaired as per product directions

Delamination

- Delamination from substrate is caused by application of membrane to a poorly prepared surface. In these instances, membrane should be removed, surface made good and membrane re-applied
- Intra-coat delamination is caused by contamination from moisture, dust of similar between membrane coats. This is avoided by protecting first coats from physical contaminants, and ensuring that there is no surface moisture, condensation or dew, before second coat is applied.
- If intra-coat delamination has occurred, delaminated membrane should be removed and a new coat reapplied.

Insufficient film thickness

- If membrane film thickness is inadequate, the membrane's waterproofing ability will be compromised
- Insufficient film thickness may lead to membrane bubbles, delamination and leakage
- Always apply the recommended number of membrane coats, at the correct coverage rate
- 2 correct thickness coats are better than one thick coat
- If in doubt, additional coats of membrane may usually be applied

Slow curing

- Slow cure of waterproofing membrane is caused by insufficient air movement or high humidity environments
- Air flow may be improved with the use of a fan
- In humid conditions, longer cure times are required, or chose a membrane suitable for these conditions.

Re-emulsification

- If waterproofing membranes are exposed to moisture before full cure has been achieved, there is a possibility that re-emulsification may occur
- In some circumstances, re-emulsification will correct itself once moisture has been removed and the membrane is allowed to fully cure
- In other circumstances, the area must be allowed to dry, any damaged membrane removed and additional membrane applied

Tearing and puncture

- Membrane tearing may occur at corners, construction joints and areas of movement when either membrane has been applied too thinly, movement is greater than membrane's ability to move, or suitable bond breaker has not been installed
- If tearing is a result of membrane applied too thinly, damaged area should be removed and repaired, including reinforcement if required
- If tearing is a result of incorrect or no bond breaker installed, damaged membrane must be removed, correct bond breaker installed and membrane reapplied
- If tearing is a result of excessive structural movement, damaged membrane must be removed, joint design and membrane reinforcement redesigned, and membrane reapplied
- Membranes may be punctured if applied over rough surfaces, are not protected from back filling or are damaged by after trades before final toppings are applied
- Areas of membrane susceptible to puncture may be reinforced with bandage, applied as part of the first coat
- Waterproofing membranes that will be back filled against, must be protected by coreflute board of similar before back filling takes place



Waterproofing Membrane Maintenance

- After membrane application, ensure that no damage has been caused by after trades before the installation of any top coating, screed or tiled finish
- Regularly remove debris from drainage to ensure that the passage of water remains free flowing
- Inspect exposed waterproofing membranes regularly and ensure that all contaminants such as animal waste and leaves etc are removed
- Any areas of damaged membrane should be repaired as soon as indentified
- If repair is required, ensure that compatible products and systems are used. If in doubt, contact the Crommelin 7 day technical advice line
- Do not expose waterproofing membranes to highly concentrated chemicals, abrasion or other potentially damaging conditions



7 day free call technical advice
P. 1800 655 711

E. service@crommelin.com.au
W. crommelin.com.au



9 318513 129509 >