


step 2

Follow these instructions to install your parts and accessories.








2x31L side mount pullout bin

installation guide

Things you need to know







- Always read the full instructions prior to installation.
- Consider possible obstructions to your parts & accessories, like hinges inside the cabinet or adjacent cabinet doors and handles, prior to installation.
- Make sure you leave plumbing and electrical work to qualified trades people. Never try this yourself.
- Make sure you always use safety gear like a mask, ear muffs and glasses when using tools.
- **Tip:** After marking out the pre-drill holes as per the instructions, take the part that is to be installed and align the appropriate holes with the markings to ensure they match up prior to pre-drilling the holes.
- If you have any questions, contact us on:
Australia: **1800 666 078** Monday to Friday between 8:00am and 6:00pm AEST, New Zealand: **0800 522 663** Monday to Friday between 8:00am and 5:00pm NZST or email: **info@kaboodlegroup.com.au**.


Hardware included




Tools you will need

To put your kaboodle kitchen waste bins together you will need the following tools.






pre-drilling for lid brackets




On both sides of your cabinet, draw a horizontal line 477mm up from the bottom. Measuring from the front of the cabinet along these lines, mark out the pre-drill holes at 192mm, 288mm and 400mm as pictured above. Use a 2mm drill bit to pre-drill holes to a depth of roughly 2.5mm.

2 x 31L side mount pullout bin pre-drilling for runners




On both sides of your cabinet, draw a horizontal line 422mm up from the bottom. Measuring from the front of the cabinet along these lines, mark out the pre-drill holes at 37mm, 229mm and 475mm as pictured above. Use a 2mm drill bit to pre-drill holes to a depth of roughly 2.5mm.

separating runners







Separate each runner (A) into two parts by extending the guide (i) and pushing up on the lever (ii) while continuing to pull apart the two components. The guide should separate easily from the runner without too much force being applied.

attaching runners




Using the lower sets of pre-drilled holes, align with the holes on the runners (A) and fix to the cabinet using 6 x 16mm wood screws (B) as pictured above.

| | | | | | | | |
|----------|--|----------|--|----------|--|----------|---|
| B |  | C |  | D |  | E |  |
| | 16mm wood screws | | lid brackets | | bin frame | | m4 8mm screws |

attaching lid brackets


5.



Using the top sets of pre-drilled holes, align with the 2nd, 5th and 7th holes on the lid brackets (C) and fix to the cabinet using 6 x 16mm wood screws (B) as pictured above.

2 x 31L side mount pullout bin reassembling runners


6.



Carefully slide the guide back into the runner. The runners should open and close smoothly if assembled correctly. Extend the runners once they have been correctly reassembled.

attaching bin frame


7.



Place the bin frame (D) carefully onto the extended runners, aligning the holes and then securing into place with the 4 x M4 8mm screws (E). **Note:** Support the runners from underneath when screwing the frame into place. Do not tighten screws.

inserting bin lid

8.




Slide the back plastic catches of the bin lid along the top of the lid brackets until both plastic catches fall into the channels at the back. The front two plastic catches should fit into the front channels at the same time.

hardware key

| | | | | |
|--|--|--|--|--|
| F  | G  | H  | I  | J  |
| door brackets | 14mm wood screws | m6 15mm screws | m5 8mm screws | m5 16mm screws |

pre-drilling for door brackets


9.



Mark out and pre-drill four holes on the inner side of your cabinet door as pictured above. Use a 2mm drill bit to pre-drill holes to a depth of roughly 2.5mm.

2 x 31L side mount pullout bin attaching door brackets

10.




Align each door mount bracket (F) with the pre-drilled holes and fix to the door panel using 4 x 14mm wood screws (G) as pictured above. Ensure the open side of the bracket faces inward and that the height adjustment screw hole is facing down.

Half screw the 2 x M6 15mm screws (H) into the height adjustment holes of the door mount brackets as pictured above.

attaching door panel


11.



Slide the door mount brackets onto the runner brackets (i), ensuring the height adjustment screws (H) slip into the notches (ii). Screw through the top and bottom holes of the runner brackets, ensuring they are as centred as possible, using 4 x M5 16mm screws (J). Next attach the 2 x M5 8mm screws (I) through the middle holes of each runner bracket.

adjusting door panel

12.




If required, you can now adjust the door panel by tightening or loosening the screws as pictured above. Once door is aligned, tighten the four screws that secure the frame to the runners.

2x31L side mount pullout bin

installing bins

13.



Place the bins into the frame to complete assembly.

Note: Max weight capacity, including door if attached, is 25kg.

Caring for your kaboodle parts and accessories

Looking after your cabinets is really easy and with the right care and maintenance they will last you for many years. Just follow these simple steps and if you need any more information you can contact us: Australia: **1800 666 078** Monday to Friday between 8:00am and 6:00pm AEST. New Zealand: **0800 522 663** Monday to Friday between 8:00am and 5:00pm NZST or email: info@kaboodlegroup.com.au.


Hinges, runners and other parts and accessories should be kept dry at all times.

To keep the mechanisms performing at their best, regularly wipe them with a dry cloth removing any dust and grime that may build up.

We offer a dedicated customer service line for advice or any questions you may have on kaboodle products.

Call customer service on:
Australia: **1800 666 078** Monday to Friday
between 8.00am and 6.00pm AEST

New Zealand: **0800 522 663** Monday to Friday
between 8.00am and 5.00pm NZST or email:
info@kaboodlegroup.com.au

| | | | |
|---|---|--|---|
| step 1 ✓ | | Your Kaboodle cabinet is now complete. | |
| step 4 |  | step 2 ✓ | You've finished adding your parts and accessories. |
| Finish off your Kaboodle Kitchen by installing your benchtop. | | step 3 | Next, follow the instructions to fit your doors and panels. |