





Drilling Instructions

Hinge Cup (Door)





Mount Plate (Cabinet Side)




۲









Apply light pressure.

•



Mounting Instructions

۲


HÄFELE

Adjusting the Door

Depth adjustment of door with SALICE mounting plates.

It is possible to adjust the door up to +2.8 mm. The slot on the metal bottom plate allows the hinge to slide. Afterwards the screw must be re-tightened.

۲




Height adjustment of door with SALICE cruciform mounting plates with slot.


Height adjustment of door of ±2 mm is possible by loosening the two fixing screws. The slots allow the mounting plates to slide in both directions. Afterwards the screws must be re-tightened.




()












۲

Lateral adjustment of door with SALICE concealed hinges.


The adjusting screw produces the lateral travel of the hinge arm from -1.5 mm up to +4.5 mm. This value is reduced to -0.5 mm when using profile door hinges and mini hinges. The door moves with respect to the furniture side without coming apart. There are no further correcting actions required.







Cup fixed with screws (countersunk head).



 (\bullet)

Salice Hinge Drilling Pattern



HÄFELE AUSTRALIA PTY. LTD ARTICLE # 483.02.423

8 MONTEREY RD DANDENONG VIC 3175 730.83.636