

## **RHEEM** CONTINUOUS FLOW



GAS



6 STAR

2-6

**PEOPLE** 



**DELIVERY** 



HEAT EXCHANGER WARRANTY<sup>1</sup>



Rheem Continuous Flow guarantees you hot water that never runs out, with quality and performance to also give you peace of mind.

## Both 50°C and 60°C models:

- 50°C models provide the added safety of a fully-tempered home at 50°C (without the cost of a tempering valve)<sup>2</sup>
- Remote Temperature Controller options for added convenience and safety
- **Digital display** for easy fault diagnosis and service
- 10 Year Heat Exchanger Warranty<sup>1</sup>
- 50°C models adjustable to deliver 50°C at the nearest tap.
- 60°C models for hot water to the kitchen and laundry where 50°C is often not hot enough<sup>2</sup>
- Flamesafe® overheat protection shuts down the heater before overheating can occur
- Rheem Q Factor hot water every time, without fluctuation when multiple taps demand hot water
- Technical support via Rheem's National Service Network
- Natural Gas or Propane
- Frost protected down to -20°C

















## **RHEEM** CONTINUOUS FLOW




SPECIFICATION		Rheem metro	Rheem 20	Rheem metro max
Model Number		876E16 874E16	876620 874620	875E26 871E26
Pre-set Temperature	°C	50 60	50 60	50 60
Number of Bathrooms		1 – 1.5	1.5 – 2	2 – 3
Gas Type		Natural Gas/ Propane	Natural Gas/ Propane	Natural Gas/ Propane
Gas Energy Rating	Stars	6	6	6
Flow Rate @ 25°C Rise	L/min	16	20	26
Min. Operating Flow Rate	L/min	2.7	2.7	2.7
Nominal Gas Consumption	MJ/hr	126	153	199
Dimensions				
Height A	mm	520	520	565
Width B	mm	350	350	350
Depth C	mm	163	163	205
Depth – from wall to Hot Water Outlet	mm	51	51	127
Depth – from wall to Cold Water Inlet	mm	43	43	53
Depth – from wall to Gas Inlet	mm	45	45	103
Weight (empty)	kg	16	16	21
Max. Water Supply Pressure	kPa	1000	1000	1000
Min. Water Supply Pressure	kPa	140	140	140
Cold Water Connection		R 3/4	R 34	R 3/4
Hot Water Connection		R 3/4	R 34	R 3/4
Gas Connection		R 34	R 34	R 3/4









- <sup>1</sup> Continuous Flow Warranty Conditions: 10 Years parts and 3 Years labour on Heat Exchanger, 3 Years parts & labour on other components, when installed in a domestic dwelling. For all other installations, the warranty period is 1 Year parts and labour on Heat Exchanger and other components. Conditions apply. See the Rheem warranty set out in the Owner's Guide & Installation
- $^{2}\,$   $60^{\circ}\text{C}$  and higher temperature models and some applications require a tempering valve in accordance with AS 3500.4.
  - Materials and data are subject to change without notice.

Instructions or view at www.rheem.com.au/warranty.

- <sup>®</sup> Registered Trademark of Rheem Australia Pty Ltd.
- ™ Trademark of SAI Global.







The Australian
Gas Association

Rheem Australia Pty Ltd.

1 Alan Street, Rydalmere, New South Wales 2116, Australia

