



FIBREGLASS & FOAMS

Diggers Fibreglass Resin Catalyst

DESCRIPTION

Diggers Fibreglass Resin Catalyst is the hardener required to set off **Diggers Fibreglass Resin** and **Diggers Casting and Embedding Resin**.

TYPICAL USES

· Curing polyester resins

FEATURES

- A colourless liquid with a mildly pungent odour
- Easy-to-use dropper bottle for more accurate measurement

APPLICATION

- 1. Mix resin with catalyst: for 100ml of resin (cold day) use 2.5 to 3ml catalyst; and for 100ml resin (hot day) use 1.5 to 2ml catalyst.
- Use a measuring cup for the amount of catalyst needed or if using the dropper bottle 1ml = 45 drops. Mix the catalyst into the resin using a flat stirring stick until a uniform colour has been achieved.
- Make allowances for temperature, humidity, depth of resin and draughts as these factors can affect the amount of catalyst needed.

SAFETY

Wear suitable protective clothing, gloves and eye/face protection when using this product.

Code	Pack Size	Unit Barcode	Carton Barcode	Ctn/Plt
FIRC01506	6 x 15ml	9312852002448	19312852002285	6 / tray
FIRC120	1 x 120ml	9311052000735	N/A	N/A





QUEENSLAND				
Tel +61 7 3308 5200				
Eav ±61 7 3308 5201				